

CO 600 NP
LINC TAPE SYSTEM
FOR NOVA COMPUTERS

REFERENCE MANUAL

COMPUTER OPERATIONS, INC.
10774 TUCKER STREET
BELTSVILLE, MARYLAND 20705

NOVEMBER 24, 1971
DOC. NO. 112

TABLE OF CONTENTS

	INTRODUCTION
1.0	GENERAL DESCRIPTION
2.0	SPECIFICATION
3.0	INSTALLATION
4.0	LINCTAPE OPERATION
5.0	BOOTSTRAP
6.0	KEYBOARD EXECUTIVE ROUTINE
7.0	LINCTAPE UTILITIES
8.0	LINCTAPE I/O INSTRUCTIONS
9.0	TAPE FORMAT
10.0	THEORY OF OPERATION
11.0	SYSTEM COMPONENTS
12.0	POWER SUPPLY
13.0	MAINTENANCE

APPENDIX

A	BOOTSTRAP LISTING
B	UTILITY LISTING
C	KEYBOARD EXEC LISTING
D	STANDARD TAPE MAP

REFERENCES

- (1) "HOW TO USE THE NOVA COMPUTERS", DATA GENERAL CORPORATION, DG-NM
- (2) "SCHEMATIC DIAGRAMS OF THE LINCTAPE/NOVA SYSTEM", COMPUTER OPERATIONS, INC.
 - COI DR. NO SCHEMATIC
 - D-10230-01 LINCTAPE MASTER CONTROLLER
(D-10144-01 FOR S/N BELOW 1016)
 - B-10164-01 LINCTAPE DRIVE CONTROL BOARD
 - D-10198-01 LINCTAPE READER/WRITER BOARD
(D-10232-01 FOR S/N BELOW 1016)
 - D-10244-01 LINCTAPE POWER SUPPLY

CO 600
LINC TAPE SYSTEM



INTRODUCTION

THIS MANUAL IS DESIGNED TO ASSIST OPERATORS, PROGRAMMERS, AND MAINTENANCE PERSONNEL IN THE USE OF THE LINCTAPE SYSTEM WITH A NOVA, SUPER NOVA, NOVA 800 SERIES, OR NOVA 1200 SERIES COMPUTER. A KNOWLEDGE OF THE OPERATION OF THE NOVA IS ASSUMED.

NO DATA GENERAL OPTIONS, EXCEPT THE I/O CONNECTOR ARE REQUIRED. HOWEVER, IT IS ASSUMED THRUOUT THIS MANUAL, THAT A TELETYPE * OR EQUIVALENT I/O DEVICE IS AVAILABLE. THE I/O CONNECTOR IS STANDARD ON THE 1210, 1220, AND 820 NOVA COMPUTERS.

* TELETYPE IS A TRADEMARK OF THE TELETYPE CORPORATION.

1.0 GENERAL DESCRIPTION

THE CO-600-NP LINCTAPE SYSTEM CONSISTS OF TWO (OR MORE) DRIVES AND A COMMON ELECTRONICS SYSTEM. EACH DRIVE HANDLES ONE REEL OF LINCTAPE.

EACH TAPE IS DIVIDED INTO SECTORS OR BLOCKS. THERE ARE 400 (620 OCTAL) SUCH BLOCKS PER TAPE, NUMBERED 0 THRU 399. EACH BLOCK CONTAINS 256 WORDS OF 16 BITS EACH. EACH BLOCK IS ADDRESSABLE AND THE TRANSFERRING OF DATA (READING OR WRITING) IS DONE ONE OR MORE BLOCKS AT A TIME. THUS, LINCTAPE IS MORE AKIN TO A DISC THAN IT IS TO INDUSTRY COMPATIBLE TAPE.

FOR INSTANCE, ASSUME THAT IT IS DESIRABLE TO SAVE A DATA BUFFER THAT EXISTS IN CORE FROM LOCATION 3000 THRU 3777 (OCTAL). IT CAN BE WRITTEN OUT ONTO LINCTAPE AS FOLLOWS:

```
SUB 0,0
DOB 0,LINC  SELECT DRIVE NO 0
LDA 0,BLKNO  LOAD AC0 WITH 1ST BLOCK NUMBER
LDA 1,NBLKS  LOAD AC1 WITH NUMBER OF BLOCKS
LDA 2,FCORE  LOAD AC2 WITH 1ST CORE LOCATION
JSR@ WLINC   JUMP TO THE WRITE UTILITY SUBROUTINE
```

--
--

```
BLKNO: 100
NBLKS: 2
FCORE: 3000
WLINC: X7406
RLINC: X7403
```

THIS ROUTINE WILL WRITE 2 BLOCKS (1000 OCTAL WORDS), STARTING AT CORE LOCATION 3000, ONTO THE LINCTAPE THAT IS ON DRIVE 0, STARTING WITH BLOCK NUMBER 100.

TO READ THE DATA BACK INTO CORE, THE SAME PROCEDURE WOULD BE USED, EXCEPT THAT THE LAST INSTRUCTION WOULD BE "JSR@ RLINC".

ONE OF THE ADVANTAGES OF LINC TAPE OVER INDUSTRY COMPATIBLE TAPE SYSTEMS IS THE ABILITY TO OVER-WRITE A BLOCK. THE SELF-SYNCHRONIZING FEATURES OF LINCTAPE ALLOW INFORMATION TO BE READ, UPDATED, AND RE-WRITTEN BACK ON THE SAME PLACE IN TAPE.

AMONG THE MAJOR USES OF LINCTAPE ARE:

1. BOOTSTRAPPING. THIS ALLOWS STARTING THE COMPUTER FROM SCRATCH BY LOADING THE LINC UTILITIES AND OTHER DESIRED PROGRAMS INTO CORE.
2. LIBRARY STORAGE. LIBRARY PROGRAMS, SUCH AS THE ASSEMBLER, DEBUG ROUTINES, AND DIAGNOSTICS, CAN BE STORED ON TAPE AND LOADED INTO CORE QUICKLY AT ANY TIME.
3. PROGRAM STORAGE. USER PROGRAMS CAN BE STORED ON LINCTAPE FOR RAPID, DIRECT ACCESS WHEN NEEDED. THREE PARAMETERS: BLOCK LOCATION, CORE LOCATION, AND NUMBER OF BLOCKS WILL SPECIFY ALL THAT IS NEEDED TO LOAD ANY OF THE PROGRAMS.
4. PROGRAM DEBUGGING. WHEN DEBUGGING PROGRAMS, THE CURRENT PROGRAM CAN BE SAVED ON LINCTAPE. IF THE PROGRAM DESTROYS CORE, IT CAN BE QUICKLY RELOADED. IF IT REQUIRES UPDATING, IT CAN BE LOADED INTO CORE, UPDATED, AND WRITTEN BACK ONTO TAPE EASILY. IF EXPERIMENTAL PROGRAM MODIFICATIONS ARE TO BE TRIED, THE ORIGINAL, AND LATER ITERATIONS, OF THE PROGRAM CAN BE SAVED.
5. PROGRAM OVERLAY. LARGE PROGRAMS CAN BE BROKEN INTO SMALLER SECTIONS AND LOADED INTO CORE A SECTION AT A TIME. THUS IT IS OFTEN POSSIBLE TO UTILIZE A MACHINE WITH LIMITED CORE TO RUN LARGE PROGRAMS USING LINCTAPE.
6. DATA STORAGE. DATA BLOCKS CAN BE STORED ON, OR READ FROM LINCTAPE IN THE STANDARD MANNER. WRITING "IN PLACE" OFTEN ALLOWS THE USE OF ONE TAPE, INSTEAD OF THE USUAL TWO THAT ARE REQUIRED FOR INDUSTRY COMPATIBLE SYSTEMS.
7. DATA MERGING. MERGING TWO DATA BUFFERS CAN USUALLY BE DONE WITH ONE DUAL LINCTAPE SYSTEM, RATHER THAN THREE INDUSTRY COMPATIBLE SYSTEMS.

2.0 SPECIFICATIONS

2.1 SYSTEM

- DUAL TAPE DRIVE
- EXPANDABLE TO 16 DRIVES (8 DUAL)
- 60 IPS TAPE SPEED IN EITHER DIRECTION
- BI-DIRECTIONAL BLOCK SEARCH AT FULL SPEED
- UPDATE ANY SECTOR(S) DIRECTLY
- WRITE PROTECT ON EACH DRIVE
- 25 SECONDS END TO END TRAVERSE TIME
- 8.5 SECONDS AVERAGE ACCESS TIME
- 130 MS START/STOP/REVERSE TIME
- 16 BIT PARALLEL INTERFACE
- ALGEBRAIC CHECKSUM FOR EACH BLOCK
- PERMANENT, PRE-RECORDED SECTOR ADDRESSES

2.2 TAPE

- SCOTCH CAT. NO. 481-3/4-150-R42 (UNMARKED)
- 150 FEET LONG
- 3/4 INCH WIDE
- 10 TRACKS, 35 MIL, FULLY REDUNDANT
- SANDWICH TAPE FOR LONG TAPE AND HEAD LIFE
- 3-13/16 INCH DIAMETER REEL
- 400 BPI PHASE RECORDING
- 16 BIT WORD
- 102,400 WORDS PER REEL (204,800 BYTES)
- 4200 WORDS/SECOND TRANSFER RATE (8400 BYTES/SECOND)
- 400 DATA BLOCKS
- 256 WORDS/BLOCK

2.3 PHYSICAL

- 8-3/4"H X 19"W X 12-3/16"D RACK MOUNT
- 2-1/8 FRONT PROJECTION
- 10-1/16 REAR PROJECTION (EXCLUDING PLUGS)
- 105-125 VOLTS, 60 HZ, 100 WATTS (50 HZ AVAILABLE)
- 35 POUNDS

2.4 MOUNTING

THE LINCTAPE IS DESIGNED FOR STANDARD RACK MOUNTING. THE DIMENSIONS ARE SHOWN IN FIGURE 2.1. IT IS ADVISABLE TO PROTECT THE HEADS, GUIDES, AND TAPE FROM DIRT AND DUST BY KEEPING THE FRONT DOOR CLOSED IN OPERATION. HOWEVER, IN A LABORATORY ENVIRONMENT, THE DOOR MAY BE REMOVED BY TWO SCREWS NEAR THE HINGE.

POWER, I/O, AND SLAVE CONNECTIONS ARE MADE IN THE REAR OF THE UNIT. ACCESS TO THE ELECTRONIC BOARDS IS MADE BY SWINGING THE REAR PANEL OR BY REMOVING THE REAR COVER OR THE TOP COVER.





FIGURE 2.1
OUTLINE DIMENSIONS

2.5 PACKING LIST

CO-600-NP MASTER LINCTAPE UNIT

- 1 EA DUAL LINCTAPE DRIVE SYSTEM WITH READ/WRITE ELECTRONICS
- 1 EA LINE CORD
- 1 EA I/O CABLE
- 2 EA REELS OF MARKED LINCTAPE
- 1 EA INSTRUCTION BOOK

CO-605 SLAVE UNIT

- 1 EA DUAL LINCTAPE SLAVE DRIVE SYSTEM
- 1 EA LINE CORD
- 1 EA SLAVE ADAPTER CABLE
- 2 EA REELS OF MARKED TAPE
- 1 EA INSTRUCTION BOOK

NOTE: ADDITIONAL LINCTAPES, PRE-MARKED AND CERTIFIED, MAY
BE OBTAINED FROM COMPUTER OPERATIONS, INC.

3.0 INSTALLATION

THE CPU MUST HAVE THE I/O CONNECTOR OPTION FOR PROPER INSTALLATION:

NOVA		DATA GENERAL	TYPE 4022
SUPERNOVA	"	"	" 8022
NOVA 800	"	"	" 8222
NOVA 1200	"	"	" 8122

STANDARD ON THE 1210, 1220, AND 820.

3.1 MOUNT THE LINCTAPE. IF THE LINCTAPE IS TO BE RACK MOUNTED:


- A. REMOVE THE DOOR BY REMOVING THE TWO SCREWS HOLDING THE HINGE BLOCK TO THE FRONT PANEL. BE CAREFUL NOT TO SCRATCH THE HEADS OR THE GUIDES.
- B. PLACE THE LINCTAPE IN POSITION AND FASTEN FIRMLY IN PLACE USING FOUR SCREWS THRU THE FLANGE SLOTS. IT IS ADVISABLE TO PROTECT THE FRONT PANEL FINISH BY USING A FIBER OR PLASTIC WASHER UNDER THE SCREW HEADS.
- C. REPLACE THE DOOR, BEING SURE IT IS POSITIONED TO CLOSE PROPERLY.

3.2 CONNECT THE POWER CABLES. IF IT IS DESIRED TO HAVE THE COMPLETE SYSTEM TURN ON AND OFF WITH THE COMPUTER POWER SWITCH:

- A. TURN OFF ALL POWER TO THE SYSTEM.
- B. PLUG THE LINCTAPE POWER CABLE INTO THE OUTLET IN THE BACK OF THE COMPUTER.
- C. PLUG THE NEXT PERIPHERAL DEVICE (SUCH AS THE TELETYPE) INTO THE OUTLET IN THE BACK OF THE LINCTAPE. REFER TO THE DATA GENERAL MANUAL TO DETERMINE THE PERMISSIBLE LOAD. LINCTAPE DRAWS ABOUT 1 AMP.

3.3 CONNECT THE I/O CABLES. THIS CONNECTION DEPENDS ON THE OTHER PERIPHERALS IN THE SYSTEM. ONE OF THE FOLLOWING CONNECTIONS SHOULD BE MADE:

- A. IF THE LINCTAPE IS THE ONLY PERIPHERAL ON THE I/O CONNECTOR, SIMPLY CONNECT THE I/O CABLE (SUPPLIED WITH LINCTAPE) BETWEEN THE COMPUTER I/O CONNECTOR AND EITHER OF THE LINCTAPE I/O CONNECTORS. LEAVE THE REMAINING CONNECTOR ON THE LINCTAPE OPEN.
- B. IF OTHER PERIPHERALS ARE TO BE CONNECTED ON THE SAME LINE, THEY CAN BE "DAISY CHAINED" BY USING BOTH CONNECTORS ON THE LINCTAPE. IN THIS CASE, CONNECT THE I/O CABLE BETWEEN THE COMPUTER AND LINCTAPE AS IN "A" ABOVE. THEN CONNECT THE NEXT PERIPHERAL CABLE TO THE REMAINING I/O CONNECTOR ON THE LINCTAPE. AT THE END OF THIS CHAIN, AN I/O TERMINATOR SHOULD BE USED. POWER FOR THE TERMINATOR MUST BE SUPPLIED BY THE LAST PERIPHERAL. SEE THE "HOW TO" MANUAL, REFERENCE 1, APPENDIX A.



* NOVA 1200 OPTION 8122
 NOVA 800 OPTION 8222
 SUPER NOVA OPTION 8022
 NOVA OPTION 4022

FIGURE 3.1
 CABLE DIAGRAM

3.4 SLAVE UNIT INSTALLATION. IF ONE OR MORE SLAVE UNITS ARE TO BE CONNECTED, THEY MAY BE STRUNG IN "DAISY CHAIN" FASHION. AS MANY AS SEVEN (7) SLAVES MAY BE SO CONNECTED, OR A TOTAL OF 16 DRIVES. SEE FIGURE 3.2.

THE TWO DRIVES ON THE MASTER UNIT ARE CONNECTED AS NUMBERS 0 AND 1. (EVEN NUMBERED DRIVES ARE ALWAYS ON THE LEFT AND ODD NUMBERED ONES ON THE RIGHT WHEN FACING THE FRONT.) SLAVE UNITS ARE NORMALLY WIRED TO BE NUMBERS 2 AND 3 AT THE FACTORY. IF ADDITIONAL SLAVES ARE ADDED, IT MAY BE NECESSARY TO CHANGE THE JUMPERS ON THE DRIVE CONTROL BOARD TO SUIT. IT IS IMPORTANT THAT NO TWO UNITS HAVE THE SAME DRIVE NUMBERS. SEE FIGURE 3.3.

TO CHANGE THE DRIVE NUMBER FOR ANY UNIT, THE FOLLOWING STEPS ARE REQUIRED:

1. DISCONNECT ALL POWER;
2. REMOVE THE 6 SCREWS ON THE TOP OF THE LINCTAPE AND REMOVE THE COVER;
3. DISCONNECT THE THREE EDGE CONNECTORS FROM THE TOP OF THE DRIVE CONTROL BOARD AND CAREFULLY REMOVE THE BOARD;
4. NOTE THE POSITION OF THE THREE JUMPER WIRES NEAR THE TOP CENTER OF THE BOARD. THEY ARE MARKED, AND THE SUM OF THE MARKINGS INDICATES THE DRIVE NUMBER OF THE LEFT HAND DRIVE. THE RIGHT DRIVE IS, OF COURSE, ONE NUMBER HIGHER. SEE FIGURE 3.3.
5. CAREFULLY UNSOLDER AND CHANGE THE NECESSARY JUMPERS TO SUIT. BE CAREFUL NOT TO DAMAGE THE PADS.
6. REPLACE THE BOARD, THE CONNECTORS, AND THE TOP COVER.





FIGURE 3.2
SLAVE CONNECTIONS



DRIVE NUMBERS 4 & 5 SHOWN

FIGURE 3.3
DRIVE NUMBER JUMPERS

4.0 LINTAPE OPERATION

THE LINTAPE SYSTEM HAS TWO DRIVES WHICH MAY BE OPERATED SEPARATELY. THE LEFT DRIVE IS NUMBERED 0 (ZERO) AND THE RIGHT DRIVE IS NUMBERED 1 (ONE). THE TAPE IS ALWAYS MOUNTED ON THE RIGHT (OR SOURCE) HUB OF EACH DRIVE. THE LEFT HUB HAS THE TAKEUP REEL WHICH SHOULD NOT BE REMOVED.

EACH DRIVE HAS THREE BUTTONS ASSOCIATED WITH IT: LOAD, REWIND, AND WRITE PROTECT. NEGLECTING WRITE PROTECT, THERE ARE FOUR MODES OF OPERATION POSSIBLE FOR EACH DRIVE: OFF, FORWARD, REVERSE, AND TENSION. WHEN POWER IS FIRST APPLIED, BOTH DRIVES WILL BE IN THE OFF MODE.

THE LOAD (OR LEFT) BUTTON IS THE WHITE MOMENTARY CONTACT BUTTON ON THE LEFT SIDE OF EACH DRIVE. IT WILL MOVE THE TAPE FORWARD. WHEN RELEASED, THE DRIVE WILL BE IN THE TENSION MODE. THE DRIVE MUST BE IN THE TENSION MODE BEFORE THE COMPUTER CAN ACCESS IT. THE OPERATOR SHOULD CHECK THE TENSION IF THE LINTAPE FAILS TO RESPOND TO COMPUTER COMMANDS.

THE REWIND (OR RIGHT) BUTTON IS THE WHITE MOMENTARY CONTACT BUTTON ON THE RIGHT SIDE OF EACH DRIVE. IT WILL MOVE THE TAPE IN THE REVERSE DIRECTION. WHEN RELEASED, THE DRIVE WILL BE IN THE OFF MODE.

THE WRITE PROTECT BUTTON IS THE RED ALTERNATE ACTION BUTTON LOCATED UNDER EACH HEAD. WHEN IT IS LIGHTED, IT IS IMPOSSIBLE FOR THE COMPUTER TO WRITE ON THE TAPE, AND THE DRIVE IS THUS PROTECTED FROM ACCIDENTAL WRITING. THE BUTTON HAS NO EFFECT ON READING.

TO MOUNT A TAPE ON EITHER DRIVE, PRESS THE REEL FIRMLY OVER THE HUB UNTIL IT SNAPS INTO PLACE. PASS THE END OF THE TAPE OVER THE GUIDES AND HEAD AND LAY IT ON THE TAKEUP REEL. HOLD THE TAPE AGAINST THE TAKEUP REEL AND WIND IT ON A COUPLE OF TURNS. TURN THE REELS TO TAKE UP ANY SLACK, AND PRESS THE LOAD BUTTON BRIEFLY. THE REELS SHOULD STOP WITH THE TAPE IN TENSION.

TO UNLOAD A TAPE, HOLD THE REWIND (OR RIGHT) BUTTON UNTIL THE TAPE UNWINDS. PULL THE REEL OFF BY PRESSING AGAINST THE HUB AND PULLING ON THE REEL UNTIL THE REEL SNAPS OFF.

CAUTION: CERTAIN PRECAUTIONS SHOULD BE OBSERVED CONCERNING ANY MAGNETIC TAPE SYSTEM, LINCTAPE INCLUDED:

- (1) BE CAREFUL OF THE HEADS AND GUIDES. DO NOT SCRATCH THEM;
- (2) KEEP THE TAPES, HEADS, AND GUIDES CLEAN. SEE SECTION 13;
- (3) KEEP TAPES AWAY FROM STRONG MAGNETIC FIELDS, SUCH AS MIGHT BE FOUND NEAR TRANSFORMERS, MOTORS, FLUORESCENT LIGHT BALLASTS, ETC.
- (4) DO NOT USE STICKY TAPE, SUCH AS "SCOTCH" TAPE OR ADHESIVE LABELS, ON THE TAPE. IN TIME, THE STICKY MATERIAL TENDS TO SEEP OUT, AND DISTRIBUTE ITSELF OVER THE TAPE AND GUIDES, CAUSING DROPOUTS. TO IDENTIFY A TAPE, PUT LABELS ON THE REEL.




FIGURE 4.1
FRONT PANEL CONTROLS

5.0 BOOTSTRAP

THE LINCTAPE BOOTSTRAP CAN BE USED WITH ANY OF THE NOVA SERIES COMPUTERS. IT ALLOWS QUICK AND EASY LOADING OF PROGRAMS FROM LINCTAPE.

THERE ARE TWO DIFFERENT PROCEDURES, DEPENDING ON WHETHER THE COMPUTER HAS A HARDWARE PROGRAM LOADER OR NOT.

THE PROCEDURE FOR THESE BOOTSTRAPS ARE DESCRIBED IN DETAIL IN APPENDIX A.

6.0 KEYBOARD EXECUTIVE ROUTINE.

THE KEYBOARD EXECUTIVE ROUTINE IS DESIGNED TO TRANSFER DATA AND PROGRAMS BETWEEN CORE AND LINCTAPE VIA THE KEYBOARD WITH A MINIMUM OF OPERATOR EFFORT. IT HAS TWO MODES OF OPERATION: GENERAL AND AUTOMATIC.

6.1 GENERAL MODE.

THE GENERAL MODE ALLOWS ANY NUMBER OF CONTIGUOUS BLOCKS OF DATA OR INFORMATION TO BE READ FROM OR WRITTEN ONTO LINCTAPE. THE FORMAT, WHICH REQUIRES 5 PARAMETERS, IS:

*1000,10,4,0R

WHERE	*	IS THE RESPONSE GIVEN BY THE KEYBOARD EXEC WHEN WAITING FOR AN OPERATOR INPUT
1000		IS THE FIRST CORE LOCATION
10		IS THE FIRST BLOCK NUMBER
4		IS THE NUMBER OF BLOCKS
0		IS THE DRIVE NUMBER
R		MEANS READ FROM TAPE INTO CORE.

THIS STRING, WHEN TYPED INTO THE KEYBOARD EXEC, WILL READ THE CONTENTS OF BLOCKS 10 THRU 13 FROM THE TAPE ON DRIVE 0 INTO CORE LOCATIONS 1000 THRU 2777. (NOTE THAT ALL NUMBERS ARE IN OCTAL.) COMMAS ARE USED TO SEPARATE THE PARAMETERS, EXCEPT NO SEPARATOR IS NEEDED BETWEEN THE DRIVE NUMBER AND THE COMMAND LETTER.

READ (R) MEANS TO TRANSFER BLOCKS OF DATA FROM LINCTAPE AND STORE THEM IN CORE. PREVIOUS DATA IN THE SPECIFIED AREAS OF CORE ARE, OF COURSE, LOST. THE DATA ON TAPE IS NOT ALTERED.

WRITE (W) MEANS TO TRANSFER BLOCKS OF INFORMATION FROM CORE AND WRITE THEM ON LINCTAPE. PREVIOUS DATA IN THE SPECIFIED BLOCKS OF TAPE ARE LOST, BUT CORE IS NOT ALTERED. AFTER WRITING, THE TAPE IS CHECKED ON A SECOND PASS.

CHECK (C) DOES NOT TRANSFER INFORMATION, BUT IT DOES CHECK AREAS OF TAPE FOR PROPER CHECKSUMS. IT IS PRIMARILY USED FOR TESTING PURPOSES.

THE KEYBOARD EXEC REQUIRES THE UTILITY SUBROUTINES TO BE IN CORE. NORMALLY, BOTH ARE RESIDENT. TO RE-ENTER THE KEYBOARD EXEC AT ANY TIME, START THE COMPUTER AT THE ENTRY LOCATION X7000 (X7777 IS THE HIGHEST CORE LOCATION).

PRECAUTIONS AND LIMITATIONS

1. THERE ARE THREE COMMANDS: READ(R), WRITE(W), AND CHECK(C);
2. ALL PARAMETERS MUST BE IN OCTAL;
3. EACH BLOCK CONTAINS 400 (256 DECIMAL) WORDS. WHOLE BLOCKS ARE ALWAYS TRANSFERRED.
4. NEGATIVE NUMBERS MUST BE ENTERED AS TWOS COMPLEMENT NUMBERS:
177776 = -2
5. BLOCK NUMBERS BELOW -6 (177772) ARE NOT ACCEPTABLE TO THE KEYBOARD EXEC, NOR ARE BLOCKS ABOVE 617 (OCTAL);
6. OVERFLOW BITS ARE IGNORED. THAT IS, ONLY THE LOWER 16 BITS OF THE TYPED NUMBER ARE USED:
77777776 = 177776 = -2
7. NUMBERS NOT TYPED ARE ASSUMED TO BE ZERO:
1000,,2,R MEANS CORE LOC 1000, STARTING BLOCK ZERO
2 BLOCKS, DRIVE 0, READ.
8. IT IS THE OPERATORS RESPONSIBILITY NOT TO READ OVER THE KEYBOARD EXEC OR THE UTILITIES. THESE RESIDE IN LOCATIONS X7000 THRU X7377 AND X7400 THRU X7777 RESPECTIVELY.

6.2 AUTOMATIC MODE

CLEARLY, IN THE GENERAL MODE, IT IS NECESSARY THAT THE OPERATOR KNOW WHERE PARTICULAR PROGRAMS OR DATA ARE STORED ON TAPE. THE AUTOMATIC MODE ALLOWS FREQUENTLY USED PROGRAMS TO BE READ (BUT NOT WRITTEN) QUICKLY, WITHOUT THE NEED TO KNOW EXACTLY WHERE THEY ARE STORED ON TAPE. FOR INSTANCE, TYPING "A" INTO THE KEYBOARD EXEC COULD LOAD THE ASSEMBLER.

EACH TYPE OF TAPE (SYSTEM, PROGRAM, ETC.) MAY HAVE DIFFERENT PROGRAMS, EACH WITH ITS OWN CODE LETTERS. THE CORE LOCATION AND BLOCK NUMBERS ARE STORED IN A TABLE IN THE KEYBOARD EXEC. THE PROPER TAPE MUST BE ON DRIVE 0 WHEN USING THE AUTOMATIC MODE. THIS AUTOMATIC MODE WILL LOAD, BUT WILL NOT EXECUTE THE CALLED PROGRAM. THE OPERATOR MUST DO THIS SEPARATELY. THIS ALLOWS SEVERAL PROGRAMS TO BE LOADED AT ONE TIME AND EXECUTED SELECTIVELY.

THE COMMAND LETTERS AND THEIR ASSOCIATED PARAMETERS MAY BE MODIFIED AS PROGRAMS ARE ADDED OR DELETED FROM THE TAPE. SEE THE EXEC LISTING FOR DETAILS.

LINCTAPES, WHEN SUPPLIED BY COI, NORMALLY CONTAIN NO PROGRAMS ON TAPE OTHER THAN THE BOOTSTRAP, UTILITIES, AND KEYBOARD EXEC. THE AUTOMATIC MODE TABLE IS EMPTY.

6.3 COMPUTER RESPONSE.

AFTER THE TRANSFER TAKES PLACE, THE TELETYPE WILL RESPOND WITH ANOTHER "**", INDICATING THAT THE PREVIOUS COMMAND WAS EXECUTED, AND THE EXEC IS WAITING FOR ANOTHER OPERATOR COMMAND.

IF AN ERROR OCCURS, THE TELETYPE WILL PRINT A "?" AND THEN THE "**". THE POSSIBLE ERRORS THAT MAY OCCUR INCLUDE:

1. DRIVE NOT READY (NOT IN TENSION MODE),
2. A WRITE ATTEMPT WAS MADE ON A PROTECTED DRIVE,
3. THE COMMAND LETTER, EITHER GENERAL OR AUTOMATIC, IS NOT VALID,
4. A NON-OCTAL NUMBER WAS TYPED,
5. A NON VALID CHARACTER (SUCH AS SPACE) WAS TYPED,
6. A NON-VALID BLOCK WAS REQUESTED (VALID BLOCKS ARE 177772 THRU 617, INCLUSIVE),
7. THE TAPE IS BAD, CONTAINING ERRONEOUS CHECKSUM, BLOCK NUMBER, ETC.

7.0 LINTAPE UTILITIES

THE LINTAPE UTILITY SUBROUTINES ARE A SET OF SOFTWARE WHICH MAKE IT EASY FOR THE PROGRAMMER TO COMMUNICATE WITH THE LINTAPE. THEY ALLOW READING AND WRITING WITH A FEW SIMPLE INSTRUCTIONS, AND RELIEVE THE PROGRAMMER OF THE DETAILS OF TIMING, BLOCK SEARCHING, ETC. ONLY DRIVE SELECTION IS LEFT UP TO THE PROGRAMMER.

NORMALLY, THE UTILITIES ARE LOADED NEAR THE TOP OF CORE, AND ARE NEVER CHANGED (THEY ARE SAID TO BE RESIDENT). THEY OCCUPY LOCATIONS X7400-X7577 (X7777 IS THE LAST LOCATION IN CORE). ALL CALLS MUST BE MADE WITH A 'JSR@' STATEMENT TO ONE OF THE FOLLOWING ENTRY POINTS:

```
CLINC  X7400  CHECK BLOCKS
RLINC  X7403  READ & CHECK BLOCKS
WLINC  X7406  WRITE & CHECK BLOCKS
```

WITH THE REGISTERS LOADED AS FOLLOWS:

```
AC0 = FIRST BLOCK NUMBER TO BE PROCESSED,
AC1 = NUMBER OF BLOCKS TO BE PROCESSED, AND
AC2 = FIRST CORE LOCATION.
```

IF AC1 = 0, THE TAPE WILL PRE-POSITION ITSELF NEAR THE BLOCK NUMBER SPECIFIED IN AC0.

IF AC2 IS NEGATIVE, THE DRIVE WILL START BACKWARD (THUS SAVING TIME IF IT IS KNOWN THAT THE BLOCK TO BE FOUND HAS BEEN PASSED), AND IT WILL TAKE THE 1'S COMPLEMENT (NOT THE NEGATIVE) OF THE NUMBER IN AC2 AS THE FIRST CORE LOCATION.

THE UTILITIES WILL RETURN TO THE PROGRAM WITH THE DRIVE STOPPED, AND THE REGISTERS CONTAINING THE FOLLOWING INFORMATION:

```
AC1 = 0 FOR NORMAL (NON-ERROR) RETURN
AC2 = NEXT BLOCK NUMBER
AC3 = NEXT CORE LOCATION
```

IF THERE IS AN ERROR, AC1 CONTAINS THE ERROR CODE:

```
AC1 = 1  IF THERE WAS A CHECKSUM ERROR:
          AC0 = BAD BLOCK NUMBER
AC1 = 2  IF THERE WAS A BLOCK SIZE ERROR:
          AC0 = BAD BLOCK NUMBER
          AC2 = EXCESS OF WORDS IN BLOCK
          AC3 = EXPECTED NUMBER OF WORDS
AC1 = 4  IF THERE WAS AN ILLEGAL BLOCK CALLED FOR
          (-6 THRU 617 ARE LEGAL NORMALLY):
          AC0 = TARGET BLOCK
          AC2 = NEXT CORE LOCATION
          AC3 = HIGHEST LEGAL BLOCK
AC1 = 8  IF THERE WAS A DRIVE STATUS ERROR:
          AC3 = DRIVE STATUS
          BIT 15 ON = DRIVE NOT READY (TENSION)
          BIT 14 ON = WRITE ATTEMPTED ON PROTECTED DRIVE
```

THE CALLING SEQUENCE IS (ASSUMING .RDX = 8):

LINC =74 ;LINCTAPE DEVICE NUMBER

LDA 0,DRVNO

DOB 0,LINC ;SELECT DRIVE NUMBER

LDA 0,FBLKN ;SET AC0 = 1ST BLOCK NO

LDA 1,NBLKS ;SET AC1 = NO OF BLOCKS

LDA 2,FCORE ;SET AC2 = 1ST CORE LOC

JSR@ RLINC ;READ THE BLOCKS

MOV 1,1,SZR ;TEST FOR ERROR

WLINC: X7406 ;WRITE POINTER

RLINC: X7403 ;READ POINTER

FBLKN: 100

NBLKS: 10

FCORE: 1000

DRVNO: 1

THE ABOVE WILL READ THE CONTENTS OF BLOCK NUMBERS 100 THRU 107
FROM THE TAPE ON DRIVE 1 INTO CORE LOCATIONS 1000 THRU 4777 (ALL
IN OCTAL, AND ASSUMING STANDARD 400 WORD BLOCKS).

8.0 LINCTAPE I/O INSTRUCTIONS

USUALLY, THE STANDARD LINCTAPE UTILITIES WILL HANDLE ALL NECESSARY COMMUNICATION BETWEEN THE LINCTAPE AND THE COMPUTER. IT IS RECOMMENDED THAT, WHENEVER POSSIBLE, THESE BE USED.

HOWEVER, IN THOSE CASES WHERE THEY ARE INADEQUATE, OR WHERE SPECIAL CONDITIONS REQUIRE CHANGES, THE ACTUAL I/O COMMANDS AND LIMITATIONS ARE GIVEN IN THIS SECTION.

THE LINCTAPE IS A PERIPHERAL DEVICE, WHICH IS ADDRESSED IN THE SAME MANNER AS ALL OTHER PERIPHERALS, THRU THE I/O COMMANDS. REFER TO THE "HOW TO USE" MANUAL, REFERENCE 1. THE COMMANDS NECESSARY FOR OPERATION OF THE LINCTAPE INCLUDE THE FOLLOWING:

- DRIVE COMMANDS
 - SELECT DRIVE NUMBER
 - START DRIVE FORWARD
 - START DRIVE BACKWARD
 - STOP DRIVE
- STATUS
 - DRIVE READY
 - WRITE PROTECT
 - BLOCK NUMBER READY
 - DATA WORD READY
 - CHECKSUM READY
- DATA TRANSFER
 - INPUT DATA WORD
 - OUTPUT DATA WORD
 - TURN WRITERS ON

SPECIFICALLY, THE FOLLOWING INSTRUCTIONS ARE APPLICABLE:

LINC = DEVICE NUMBER 74 (OCTAL) NORMALLY

DATA I/O.

- DIA X,LINC INPUT THE 16 BIT DATA WORD TO ACX.
- DOA X,LINC OUTPUT THE 16 BIT WORD IN ACX TO THE LINCTAPE.
- DIB X,LINC INPUT THE STATUS BITS TO ACX
 - BIT 15 ON = NOT READY
 - BIT 14 ON = WRITE PROTECTED
- DOB X,LINC SELECT DRIVE NUMBER. THE DRIVE NUMBER MUST BE IN THE 4 LOW ORDER BITS OF ACX.
- DOC X,LINC TURN WRITER ON. THE WRITERS ARE AUTOMATICALLY TURNED OFF AT THE END OF EACH BLOCK. THE VALUE OF X IS ARBITRARY. ANY ACX MAY BE USED.

CONTROL PULSES. THESE MAY BE COMBINED WITH ANY OF THE I/O COMMANDS IN THE USUAL MANNER:

- S START THE SELECTED DRIVE FORWARD;
- P START THE SELECTED DRIVE BACKWARD;
- C STOP THE DRIVE. THE DRIVE DOES NOT STOP AUTOMATICALLY AT THE END OF A BLOCK. THIS ALLOWS RAPID TRANSFER OF SUCCESSIVE BLOCKS, BUT IT MEANS THE PROGRAM MUST STOP THE DRIVE. IT SHOULD NOT BE STOPPED UNTIL THE NEXT BLOCK NUMBER IS READY, ESPECIALLY ON WRITING.

SKIP LINES. THERE ARE FOUR POSSIBLE CONDITIONS: (1) BLOCK NUMBER READY, (2) DATA READY, (3) CHECKSUM READY, OR (4) NONE OF THEM READY.

SKPDN LINC SKIP IF DATA OR CHECKSUM IS READY;
SKPDZ LINC SKIP IF BLOCK OR NONE IS READY;
SKPBN LINC SKIP IF BLOCK NUMBER OR CHECKSUM IS READY;
SKPBZ LINC SKIP IF DATA OR NONE READY.

NOTE THAT IT REQUIRES TWO SKIP COMMANDS TO DETERMINE WHETHER A SPECIFIC TYPE OF WORD IS READY. NOTE ALSO THAT ALL COMMANDS EXCEPT DRIVE SELECT, APPLY TO THE SELECTED DRIVE ONLY.

SPECIAL

IORST STOP DRIVE AND SELECT DRIVE 0;
FRONT PANEL RESET IS THE SAME AS IORST.

FOR EXAMPLES OF THIS PROGRAMMING, REFER TO THE LISTINGS OF THE LINCTAPE UTILITIES.

TIMING

IN MOST CASES, TIMING IS NOT CRUCIAL. OCCASSIONALLY, HOWEVER IT IS IMPORTANT THAT THE PROGRAMMER KNOW SOME OF THE BASIC TIMES INVOLVED. THE FOLLOWING ARE APPROXIMATE, AND MAY VARY BY 10 % IN THE FORWARD DIRECTION AND 30 % IN THE REVERSE DIRECTION. SEE THE DIAGRAM IN FIGURE 10.2.

TAPE END TO END	25 SECONDS
START/TURN AROUND TIME	130 MILLISECONDS
BLOCK TO BLOCK	63 MILLISECONDS (256 WORD BLOCKS)
WORD TO WORD	240 MICROSECONDS
READY (BLOCK, DATA, CKSM)	40 MICROSECONDS (RESET BY DATA TRANSFER).

MUST INPUT OR OUTPUT THE WORD DURING THIS TIME.

IN GENERAL, THE FOLLOWING RULES SHOULD BE OBSERVED:

1. DRIVE SELECTION SHOULD PRECEDE ANY MOTION;
2. DRIVE SELECTION SHOULD BE FOLLOWED BY A STATUS CHECK TO SEE IF (1) THE DRIVE IS READY AND (2) IT IS NOT PROTECTED WHEN WRITING;
3. DRIVE MAY BE STARTED FORWARD OR BACKWARD;
4. AN ACCELERATION DELAY OF 130 MS ALWAYS OCCURS WHEN STARTING OR CHANGING DIRECTION;
5. MARKS ARE TRUE FOR 36 TO 44 US FORWARD, AND 30 TO 50 US WHEN MOVING BACKWARD;
6. "BUSY" AND "DONE" ARE ENCODED FOR MARK SENSING. THEY ARE RESET WHENEVER A DIA OR DOA COMMAND IS SENT, SO A MARK CANNOT BE DOUBLY DETECTED.
7. FOLLOWING DETECTION OF ANY MARK IN A SKIP LOOP, A DIA OR DOA MUST BE ISSUED TO CLEAR THE DONE AND BUSY LINE, EVEN IF THE MARK WAS NOT THE TYPE DESIRED.
8. MOTION COMMANDS MAY BE REPEATED WHILE MOVING WITHOUT CAUSING ACCELERATION DELAY. MOTION MAY BE REVERSED WITHOUT STOPPING.
9. "WRITERS ON" COMMAND MUST NEVER BE GIVEN WHILE THE DRIVE IS GOING BACKWARD;
10. "WRITERS ON" COMMAND MUST BE GIVEN AFTER THE BLOCK MARK IS SENSED, BUT BEFORE THE FIRST DATA MARK COMES TRUE. THIS IS 220 US NOMINALLY.
11. AFTER A WRITE, MOTION MAY NOT BE CHANGED OR STOPPED UNTIL THE NEXT BLOCK MARK IS DETECTED. IN GENERAL, MOTION DECISIONS SHOULD BE MADE ONLY ON BLOCK MARKS.
12. SHOULD THE DRIVE STATUS CHANGE TO "NOT READY" DURING THE PROGRAM OPERATION, TAPE MOTION IS CLEARED AND MARKS CANNOT BE DETECTED UNTIL THE DRIVE IS RE-TENSIONED AND FORWARD OR START BACKWARD COMMAND IS GIVEN;

9.0 LINTAPE FORMAT

TO UNDERSTAND THE OPERATION OF THE LINTAPE, IT IS NECESSARY TO VISUALIZE THE FORMAT ON THE TAPE. THIS SECTION DESCRIBES THE LINTAPE ITSELF.

9.1 PHYSICAL DESCRIPTION

THE TAPE IS 150 FEET LONG, AND 3/4 INCH WIDE. IT IS ABOUT 0.0015 INCHES THICK, AND THE OXIDE IS SANDWICHED BETWEEN TWO LAYERS OF MYLAR.

THE TAPE IS DIVIDED, BY ITS PRE-WRITTEN MARKINGS, INTO THREE SECTIONS: FRONT LEADER, DATA BLOCKS, AND TRAILER. SEE FIGURE 9.1.

9.2 FRONT LEADER

THE FRONT LEADER HAS THREE PARTS: BLANK AREA, END ZONE, AND PRELIMINARY BLOCKS

9.2.1 BLANK AREA

THIS IS A SMALL AREA AT THE BEGINNING OF THE TAPE WHICH HAS NO MARKS OF ANY KIND. IT IS ABOUT TWO FEET LONG.

9.2.2 END ZONE

THE END MARKS AT THE FRONT OF THE TAPE ARE USED TO ASSURE THAT THE TAPE, ONCE UP TO SPEED, HAS SYNCHRONIZING INFORMATION. IT IS ESSENTIAL, WHEN BOOTSTRAPPING, THAT THE TAPE BE STARTED IN THIS AREA SO THAT THE FIRST BLOCK WILL BE PROPERLY LOADED. THUS THIS END ZONE MUST BE LONG ENOUGH THAT THE OPERATOR WILL NOT EASILY OVERSHOOT IT WHEN MANUALLY LOADING. A VISUAL MARKER ON THE TAPE HELPS TO ASSURE THIS. THIS END ZONE IS SEVERAL FEET LONG.

9.2.3 PRELIMINARY BLOCKS

THE FIRST FEW BLOCKS ARE USED FOR BOOTSTRAPPING AND FOR STORING SPECIAL PROGRAMS. THEY ARE GIVEN NEGATIVE BLOCK NUMBERS, SO THE PROGRAMMER CAN NORMALLY USE ALL POSITIVE BLOCKS WITHOUT DESTROYING THIS AREA. STANDARD TAPES HAVE 8 SUCH BLOCKS, NUMBERED -8 THRU -1. OTHERWISE, THESE BLOCKS ARE IDENTICAL TO DATA BLOCKS.

9.3 DATA BLOCKS

THE MAIN DATA ON TAPE IS CONTAINED IN 400 ADDRESSABLE BLOCKS, EACH CONTAINING 256 (400 OCTAL) 16 BIT WORDS. EACH BLOCK ALSO CONTAINS ITS CHECKSUM, ITS OWN BLOCK NUMBER, AND OTHER HOUSEKEEPING INFORMATION. EACH BLOCK IS ABOUT 4 INCHES LONG.

9.3.1 BLOCK NUMBERS

THERE ARE TWO BLOCK NUMBERS FOR EACH BLOCK. ONE IS AT THE BEGINNING OF EACH BLOCK AND CAN BE READ IN THE FORWARD DIRECTION. THE OTHER IS AT THE END OF EACH BLOCK AND CAN BE READ ONLY IN THE REVERSE DIRECTION.

9.3.2 DATA WORD

EACH 16 BIT DATA WORD OCCUPIES SIX LONGITUDINAL CHARACTERS ON TAPE. THERE ARE THREE DATA TRACKS AND ONE MARK TRACK. THIS ALLOWS FOR 18 DATA BITS, OF WHICH ONLY 16 ARE USED, AND FOR SIX MARK BITS.

9.3.3 CHECKSUM

THIS IS THE SUM, MODULO 65,536 (2^{16}), OF ALL WORDS IN A GIVEN BLOCK. IT IS OBTAINED BY SIMPLY ADDING EACH WORD IN THE COMPUTER AND IGNORING ANY OVERFLOW. THIS WORD IS WRITTEN ON THE TAPE IMMEDIATELY FOLLOWING THE LAST DATA WORD IN EACH BLOCK.

9.4 TRAILER

THE TRAILER, LIKE THE LEADER, HAS THREE ZONES: FINAL BLOCKS, END ZONE, AND BLANK TAPE.

9.4.1 FINAL BLOCKS

THE FINAL BLOCKS, NUMBERED 620 THRU 627 ARE NECESSARY FOR TURN-AROUND SPACE. SINCE THE TAPE "COASTS" ONE OR TWO BLOCKS PAST THE LAST BLOCK ADDRESSED, AND SINCE THE TAPE USUALLY STARTS IN THE FORWARD DIRECTION TO LOCATE ITS POSITION, SEVERAL INCHES OF IDENTIFIED SPACE IS NEEDED AFTER THE LAST USABLE BLOCK.

9.4.2 END ZONE

THIS IS USED FOR IDENTIFICATION WHEN MARKING TAPES, AND IS NOT NORMALLY USED BY THE PROGRAMMER.

9.4.3 BLANK ZONE

THIS IS THE END OF THE TAPE WITH NO MARKS.

9.5 TRACKS

THERE ARE 10 TRACKS: ONE TIMING, ONE MARK, THREE DATA, AND THESE SAME TRACKS REPEATED (REDUNDANT).

9.5.1 TIMING

THE TIMING TRACKS CONTAIN A SYNCHRONIZING SQUARE WAVE WHICH IS USED TO CLOCK THE REST OF THE SYSTEM.

9.5.2 MARK

THE MARK TRACKS CONTAIN A UNIQUE SET OF CODES WHICH IS USED TO IDENTIFY THE INFORMATION ON THE CORRESPONDING DATA TRACKS.

9.5.3 DATA TRACKS

THE THREE SETS OF DATA TRACKS CONTAIN THE LOW, MEDIUM, AND HIGH ORDER SIX BITS OF INFORMATION (THE TWO HIGH ORDER BITS ARE NOT USED).

9.5.4 BIT PLACEMENT

FIGURE 9.1 SHOWS THE ARRANGEMENT OF BITS ON THE TAPE. IT ILLUSTRATES THE TRACK REDUNDANCY AND THE RELATIONSHIP OF THE MARK TRACK.




FIGURE 9.1
LINC TAPE FORMAT

10.0 THEORY OF OPERATION

LINCTAPE, UNLIKE INDUSTRY COMPATIBLE TAPE, DOES NOT HAVE TO STOP SUDDENLY IN A PARTICULAR RECORD GAP. SINCE LINCTAPE HAS CODED MARKS ON THE TAPE ITSELF, IT IS ALWAYS POSSIBLE TO KNOW EXACTLY WHERE ON THE TAPE THE DATA IS BEING READ OF WRITTEN. THIS LEADS TO SEVERAL ADVANTAGES:

- THE DRIVE SYSTEM IS SIMPLE WITH VERY FEW MOVING PARTS;
- THE TAPE ACCELERATION CAN BE SLOWER, THUS HANDLING THE TAPE MORE GENTLY;
- THE COMPUTER DOES NOT NEED TO KEEP TRACK OF THE TAPE POSITION, SINCE THIS CAN BE FOUND ON THE TAPE ITSELF;
- DATA CAN BE WRITTEN OVER OLD DATA PRECISELY, WITHOUT DANGER OF UNDER- OR OVER-WRITING ADJACENT RECORDS;
- BLOCK SEARCHING CAN BE DONE IN EITHER DIRECTION.

THE LINCTAPE SYSTEM CONSISTS OF MAGNETIC TAPE WITH FIVE EFFECTIVE TRACKS. FIGURE 10.1 SHOWS THE BASIC BLOCK DIAGRAM, AND FIGURE 9.1 ILLUSTRATES THE TAPE PATTERNS.

THE TIMING TRACK IS USED TO SYNCHRONIZE THE INFORMATION FROM ALL OTHER TRACKS. IT IS A SIMPLE SQUARE WAVE, 90 DEGREES OUT OF PHASE FROM THE OTHER TRACKS. THIS ALLOWS THE EDGES OF THE TIMING SIGNAL TO STROBE ALL OTHER DATA.

THE MARK TRACK IS THE KEY TO THE LINCTAPE SYSTEM. IT IS A SERIES OF UNIQUE, SIX BIT CODES WHICH IDENTIFY THE INFORMATION IN THE CORRESPONDING DATA TRACKS. THESE CODES SPECIFY WHEN THE DATA, CHECKSUM, OR BLOCK NUMBERS ARE AVAILABLE IN THE DATA REGISTERS.

THE THREE DATA TRACKS CONTAIN 6 BITS OF DATA PER TRACK FOR A TOTAL OF 18 BITS. TWO BITS ARE UNUSED. THESE TRACKS ALSO CONTAIN THE CHECKSUM (FOLLOWING THE LAST DATA WORD), AND THE FORWARD AND REVERSE BLOCK NUMBERS, AT THE BEGINNING AND END OF EACH BLOCK, RESPECTIVELY.

AS THE TAPE MOVES WHILE READING, THE BITS FROM TAPE ARE SHIFTED SERIALLY INTO THE FOUR SHIFT REGISTERS AT A 25 KHZ RATE. WHEN THE PATTERN IN THE MARK REGISTER IS 41(OCTAL), THE MARK DECODING CIRCUITRY SETS THE "DATA READY" LINE. DURING THIS TIME, THE DATA REGISTERS CONTAIN THE CORRESPONDING DATA WORD. OTHER BIT PATTERNS DEFINE THE CHECKSUM AND THE BLOCK NUMBER. THESE PATTERNS ARE SIX BITS, OR 240 MICROSECONDS APART.

DURING WRITING, THE NEXT DATA WORD TO BE WRITTEN IS JAMMED INTO THE SHIFT REGISTERS WHEN THE "DATA READY" COMES TRUE, AND THE WORD IS SHIFTED, BIT BY BIT, INTO THE DATA WRITERS. SPECIAL "FINAL" MARK CODES ARE USED TO DIFFERENTIATE READING AND WRITING TIMING. SEE FIGURE 10.2.

A CHECKSUM IS WRITTEN AT THE END OF EACH BLOCK. THIS SUM IS THE ALGEBRAIC SUM, MODULO 65,536, OF ALL THE WORDS IN THE BLOCK. THE CHECKSUM IS CALCULATED AND WRITTEN BY THE WRITE PROGRAM (UTILITIES) DURING THE WRITING OF EACH BLOCK. DURING THE READING OF EACH BLOCK, THE SUM OF THE INCOMING DATA IS CALCULATED AND COMPARED WITH THE CHECKSUM ON THE TAPE.





Figure 10.1 Basic LINC Tape Block Diagram



NOTE: THIS TIMING DIAGRAM REPRESENTS POSITIVE TRUE LINES. THE LINCTAPE I/O LINES ARE GROUND TRUE.

FIGURE 10.2 TIMING FOR FORWARD MOTION.

THE FIVE HEAD SIGNALS ARE DERIVED FROM TEN ACTUAL TRACKS ON THE TAPE. ALL DATA IS RECORDED REDUNDANTLY: I.E., THERE ARE TWO CLOCK CHANNELS, TWO MARK CHANNELS, AND THREE PAIRS OF DATA CHANNELS. IDENTICAL INFORMATION IS RECORDED ON EACH CORRESPONDING TRACK. SEE FIGURE 9.1. WITHIN THE HEAD, THE CORRESPONDING HEAD PAIRS ARE WIRED IN SERIES. IF A DROPOUT SHOULD OCCUR IN A GIVEN TRACK DUE TO DIRT, POOR OXIDE, ETC., THE SIGNAL FROM THE OTHER TRACK IS SUFFICIENTLY LARGE TO INSURE PROPER READING OF THE DATA. THE CLOCK AND MARK CHANNELS ARE AT THE EXTREME EDGES OF THE TAPE TO MINIMIZE SKEW PROBLEMS. THE DATA TRACKS ARE POSITIONED TO MAINTAIN MAXIMUM SEPARATION BETWEEN CORRESPONDING CHANNELS. IT IS THE FULLY REDUNDANT NATURE OF THE RECORDING PROCESS THAT IS RESPONSIBLE FOR THE HIGH RELIABILITY OF THE LINCTAPE SYSTEM.

A TAPE MUST BE PRE-MARKED BEFORE IT CAN BE USED. THIS PRE-MARKING WRITES THE NECESSARY DATA INTO THE TIMING AND MARK TRACKS, AND WRITES THE BLOCK NUMBERS. IN OPERATION, THIS PRE-MARKED DATA CANNOT BE CHANGED. SINCE THE TAPE IS MARKED AND EACH BLOCK IS IDENTIFIED, IT IS UNNECESSARY TO KNOW WHERE THE TAPE IS TO LOCATE A SPECIFIC BLOCK. THE PROGRAM (UTILITIES) SIMPLY READS WHERE IT IS AND TAKES APPROPRIATE ACTION.

A MORE DETAILED BLOCK DIAGRAM OF THE LINCTAPE SYSTEM IS SHOWN IN FIGURES 10.3 AND 10.4.




FIGURE 10.3
LINC TAPE BLOCK DIAGRAM:
DATA REGISTERS




FIGURE 10.4
LINC TAPE BLOCK DIAGRAM:
CONTROL, MARK, & TIMING

11.0 SYSTEM COMPONENTS

THIS SECTION DESCRIBES THE MAJOR COMPONENTS OF THE LINCTAPE SYSTEM AND ILLUSTRATES THEIR LOCATION AND INTER-RELATION. SEE FIGURE 11.1 FOR THE PHYSICAL LAYOUT.

11.1 MASTER CONTROL BOARD

THE MASTER CONTROL BOARD IS THE CENTRAL LOGIC BOARD FOR THE COMPLETE LINCTAPE SYSTEM. IT INTERFACES TO THE COMPUTER, AND TO ALL SLAVE UNITS. IT ALSO CONNECTS TO THE DRIVE CONTROL BOARD AND THE READER-WRITER BOARD. IT IS THE "WIRE-WRAP" BOARD ON THE BACK DOOR OF THE MASTER UNIT. ONLY ONE OF THESE BOARDS IS REQUIRED, REGARDLESS OF THE NUMBER OF SLAVE UNITS ON THE SYSTEM. THE SCHEMATICS FOR THIS BOARD ARE SHOWN IN COI DRAWING NUMBER D-10230-01 (D-10144-01 FOR S/N BELOW 1016).

11.2 DRIVE CONTROL BOARD

THE DRIVE CONTROL BOARD IS LOCATED DIRECTLY BEHIND THE FRONT PANEL. IT CONTAINS MUCH OF THE MOTOR CONTROL LOGIC, THE HEAD SWITCHING DIODES, AND THE FRONT PANEL SWITCH LOGIC. THREE CONNECTORS AT THE TOP OF THE BOARD CONNECT TO 115 VAC, TO LOGIC SIGNALS FROM THE MASTER CONTROL BOARD, AND HEAD SIGNALS RESPECTIVELY. THIS BOARD IS IDENTICAL (EXCEPT FOR JUMPER WIRES) IN THE MASTER AND ALL SLAVE UNITS. THE SCHEMATICS FOR THIS BOARD ARE IN COI DRAWING NUMBER B-10164-01.

11.3 READER/WRITER BOARD

THIS P.C. BOARD, MOUNTED ON THE BACK DOOR OF THE MASTER UNIT, CONTAINS THE HEAD WRITER DRIVERS, AND THE HEAD READER AMPLIFIERS. ONLY ONE READER/WRITER BOARD IS REQUIRED PER SYSTEM, REGARDLESS OF THE NUMBER OF SLAVE UNITS. INTERCONNECTIONS TO THE R/W BOARD ARE MADE THRU THREE 16 PIN CONNECTORS WHICH PLUG INTO THE MAIN CONTROL BOARD. THE SCHEMATIC FOR THIS BOARD IS SHOWN IN COI DRAWING NUMBER D-10198-01 (D-10232-01 FOR S/N BELOW 1016).

11.4 POWER SUPPLY

THE POWER SUPPLY IS BEHIND THE DRIVE CONTROL BOARD. THE TERMINALS CAN BE ACCESSED BY OPENING THE BACK DOOR. IT SUPPLIES THREE D.C. VOLTAGES AND A "POWER FAIL" LOGIC SIGNAL. SEE COI DRAWING NUMBER D-10244-01.

11.5 INTERCONNECTION

THE INTERCONNECTION CABLING BETWEEN THE BOARDS AND CONNECTORS IS SHOWN IN FIGURE 11.2.




FIGURE 11.1
 LOCATION OF MAJOR COMPONENTS
 OF THE
 MASTER LINC TAPE UNIT




FIGURE 11.2
CABLE INTERCONNECTION

12.0 POWER SUPPLY

THE POWER SUPPLY FURNISHES D.C. POWER FOR THE COMPLETE LINCTAPE SYSTEM. IT IS SUFFICIENT TO SUPPLY ANY NUMBER OF SLAVE UNITS.

INPUT	115 V, 50/60 HZ
OUTPUT	+5 V @ 2.5 AMPS
	-5 V @ 0.15 AMPS
	+15 V @ 2.0 AMPS

IN ADDITION, THERE IS A LOGIC LEVEL OUTPUT WHICH INDICATES THE LINE STATUS AND IS USED TO PROTECT THE TAPE WHEN POWERING UP OR DOWN, OR WITH POWER FAILURE.

THE +15 VOLT SUPPLY IS DELAYED UPON POWER UP UNTIL THE +5 VOLT SOURCE HAS STABILIZED AND THE LOGIC LEVEL HAS RESET THE CRITICAL REGISTERS TO A SAFE STATE.

WHEN POWERING DOWN, (OR UPON POWER FAILURE) THE +15 VOLT SUPPLY IS CROWBARRED AND THE LOGIC LEVEL IS PULLED DOWN BEFORE THE +5 VOLT SUPPLY CAN FALL. THIS PREVENTS ANY ACCIDENTAL WRITING ON TAPE. THE -5 VOLT SUPPLY IS NOT CRITICAL, AND IS NOT DELIBERATELY SEQUENCED.

FIGURE 12.1 SHOWS THE APPROXIMATE POWER ON AND OFF SEQUENCING.





FIGURE 12.1

13.0 MAINTENANCE

ALTHOUGH LINTAPE IS RELATIVELY MAINTENANCE-FREE, THERE ARE A FEW MINOR MAINTENANCE STEPS WHICH WILL HELP ASSURE LONG, TROUBLE-FREE SERVICE:

1. PERIODICALLY, CLEAN THE HEADS AND TAPE GUIDES. USE A SOFT, CLEAN CLOTH (JOHNSON STERI-PAD GAUZE PADS ARE GOOD) AND AN APPROVED, UNCONTAMINATED HEAD CLEANING SOLVENT (SUCH AS AMPEX HEAD CLEANER, PART NUMBER 7010110). THIS SHOULD BE DONE FROM ONCE A DAY TO ONCE A WEEK, DEPENDING ON USE AND THE ENVIRONMENTAL CONDITIONS. DO NOT LET THE SOLVENT CONTACT THE TAPE. BE SURE THE HEAD AND GUIDES ARE DRY BEFORE MOUNTING THE TAPE. DO NOT SCRATCH THE HEADS OR THE GUIDES.
2. THE TAPES THEMSELVES OCCASSIONALLY GET DIRTY. THIS IS THE PROBABLE CAUSE OF A TAPE "HUNTING" FOR A BLOCK. ONE CAN BE CLEANED BY PASSING IT BETWEEN TWO CLEAN GAUZE PADS. MOUNT THE TAPE IN THE USUAL MANNER, PLACE ONE PAD ON THE HEAD AND HOLD THE OTHER ON THE TAPE, AND WIND THE TAPE SO THE WHOLE LENGTH PASSES BETWEEN THE PADS. BE CAREFUL NOT TO DAMAGE THE EDGES OF THE TAPE.

CAUTION: NEVER USE STICKY TAPE, SUCH AS "SCOTCH" TAPE OR ADHESIVE LABELS ON THE TAPE ITSELF. IN TIME, THE GUMMY MATERIAL TENDS TO DISTRIBUTE ITSELF OVER THE TAPE AND CAUSE DROPOUTS. PUT LABELS ON THE REEL, NOT THE TAPE. ALSO, KEEP TAPES AWAY FROM STRONG MAGNETIC FIELDS, SUCH AS NEAR TRANSFORMERS, MOTORS, OR FLUORESCENT LIGHT BALLASTS.

WHEN DIAGNOSING TROUBLES, THE FOLLOWING CHECKS ARE HELPFUL:

1. DO THE WRITE PROTECT LIGHTS WORK? IF SO, THE +15 VOLT IS PROBABLY OK.
2. DO THE LOAD AND REWIND BUTTONS WORK? FOR BOTH DRIVES? CAN THE RELAYS BE HEARD? IF SO, THE 110V AND +5 VOLT SUPPLY ARE PROBABLY OK.
3. ARE THE SHAFTS FREE TO TURN WITHOUT BEING SLOPPY? ARE ALL FOUR OF THEM ABOUT THE SAME? DO THE REELS SNAP ONTO THE HUBS PROPERLY? ARE THEY SO LOOSE THAT THE REELS SQUEAK WHEN MOTION STARTS?
4. ARE THE HEADS, GUIDES, AND TAPE CLEAN? IF THESE ARE DIRTY, THEY WILL CAUSE DROPOUTS.
5. IS THE TROUBLE INTERMITTENT? DOES IT COME AND GO WHEN WIRES ARE MOVED? IS IT ASSOCIATED WITH ONE DRIVE? ONE TAPE?
6. DOES THE CPU WORK? WITH OTHER PERIPHERALS?
7. DOES THE CPU TRANSFER DATA IN AND OUT OF THE REGISTERS PROPERLY?
8. DOES THE CPU START AND STOP TAPE? CAN THE RELAYS BE HEARD?
9. DOES THE CPU SELECT DRIVES? CAN THE RELAYS BE HEARD?
10. DOES THE CPU FIND BLOCK MARKS? DATA MARKS? CHECK MARKS?

BASED ON THE ABOVE OBSERVATIONS, THE FOLLOWING FAULTS MIGHT OCCUR:

1. POWER OFF OR SYSTEM NOT PLUGGED IN.
2. FUSE BLOWN: THERE ARE FOUR FUSES IN THE POWER SUPPLY AND ONE IN EACH OF THE DRIVE CONTROL BOARDS (MASTER AND SLAVES).
3. LOOSE CONNECTIONS: CHECK THE CONNECTORS ON THE REAR PANEL, AND ALL CONNECTORS INSIDE THE UNITS. ARE ALL TERMINALS TIGHT AND CLEAN? SOMETIMES TERMINALS CAN BE SQUEEZED SLIGHTLY TO MAKE THEM TIGHTER. EDGE TERMINAL FINGERS CAN BE CLEANED WITH AN ERASER.
4. LOOSE IC'S: REMOVE THE I.C. COVER AND PRESS ALL IC'S FIRMLY IN PLACE. BE SURE NONE ARE MISSING.
5. POWER FAIL CROWBAR HUNG UP: TURN OFF POWER FOR A FEW SECONDS AND TRY AGAIN.
6. MECHANICAL FAILURE: CHECK TO BE SURE THE HUBS AND SPROCKETS ARE FIRMLY FASTENED TO THE SHAFTS. INSPECT THE BELT FOR WEAR. BE SURE THEY ARE MECHANICALLY FREE. THE HUB SPRING TENSION CAN BE CHANGED BY MOVING OR REPLACING THE RUBBER BAND UNDER THE SPRING.

SOME IMPORTANT TIMING POINTS THAT CAN BE OBSERVED WHILE THE TAPE IS MOVING FORWARD ARE:

TREA+ 40 US SQUARE WAVE

ALL OTHER READER SIGNALS ARE RECTANGULAR WAVES WITH TRANSITIONS 20 OR 40 US APART

ACIP+ 130 MS PULSE WHEN STARTING MOTORS OR CHANGING THEIR DIRECTION

BMRK+, GMRK+ 40 US PULSE EVERY 63 MS

DMRK+ 255 40 US PULSES EACH BLOCK, 240 US APART

FMTN+ MUST BE ON FOR MARKS TO DECODE, BUT THE READER SIGNALS CAN BE MONITORED BY MANUALLY MOVING TAPE.

APPENDIX A. BOOTSTRAP

```
; LINTAPE NOVA BOOTSTRAP ROUTINE 9/27/71
;
; THERE ARE THREE METHODS OF BOOTSTRAPPING,
; DEPENDING UPON THE HARDWARE CONFIGURATION:
; (1) SUPERNOVA PROGRAM LOADER,
; (2) NOVA 800/1200 SERIES AUTOPROGRAM OPTION, OR
; (3) NOVA OR 800/1200 SERIES MANUAL BOOTSTRAP.
;
; THE LINTAPE BOOTSTRAP CAN BE USED WITH ANY
; OF THESE TO LOAD IN THE LINTAPE UTILITIES AND LOAD
; AND EXECUTE THE EXECUTIVE SYSTEM ROUTINE.
;
; THIS EXECUTIVE SYSTEM ROUTINE WILL DEPEND
; ON THE TYPE OF TAPE BEING USED. THE KEYBOARD
; EXECUTIVE ROUTINE IS ONE EXAMPLE OF AN
; EXECUTIVE SYSTEM ROUTINE.
;
; <<<<< PROCEDURES >>>>>
;
; THE PROCEDURE FOR BOOTSTRAPPING WITH THE SUPERNOVA
; PROGRAM LOADER OR THE NOVA 800/1200 SERIES
; AUTOPROGRAM OPTION IS:
; (1) SET THE DATA SWITCHES TO THE LINTAPE DEVICE
; NUMBER (USUALLY 74),
; (2) PUT A LINTAPE WITH THE NOVA BOOTSTRAP ROUTINE
; ON DRIVE 0, WITH THE MARKER TO THE RIGHT
; OF THE HEAD. LEAVE IN TENSION MODE,
; (3) PRESS RESET,
; (4) PRESS PROGRAM LOAD. THE LINTAPE WILL
; MOVE AND STOP, AND THE TELETYPE WILL RESPOND
; WITH THE APPROPRIATE EXECUTIVE SYSTEM
; RESPONSE.
;
; THE PROCEDURE FOR BOOTSTRAPPING WHEN USING
; THE MANUAL BOOTSTRAP IS:
; (1) BE SURE THE MANUAL BOOTSTRAP IS IN CORE.
; IT IS LISTED BELOW,
; (2) SET THE DATA SWITCHES TO X7770, WHERE
; X7777 IS THE HIGHEST CORE LOCATION,
; (3) PUT A LINTAPE WITH THE NOVA LOADER ON
; DRIVE 0, WITH THE MARKER TO THE RIGHT
; OF THE HEAD. LEAVE IN TENSION MODE,
; (4) PRESS RESET,
; (5) PRESS START. THE LINTAPE WILL MOVE
; AND STOP, AND THE TELETYPE WILL RESPOND WITH
; THE APPROPRIATE EXECUTIVE SYSTEM RESPONSE.
```

```

; TO LOAD THE MANUAL BOOTSTRAP INTO CORE:
;   (1) SET THE DATA SWITCHES TO X7755 (1ST LOC),
;   (2) PRESS EXAMINE,
;   (3) SET THE DATA SWITCHES TO 177737 (1ST WORD),
;   (4) PRESS DEPOSIT,
;   (5) SET THE DATA SWITCHES TO THE NEXT WORD,
;   (6) PRESS DEPOSIT NEXT,
;   (7) REPEAT (5) AND (6) UNTIL ALL WORDS ARE
;       LOADED.
;
; LOC      WORD
; -----
; X7755 177737 COUNT: -41 ;WORDS LOADED
; X7756 126420 GET: SUBZ 1,1 ;CLEAR AC1 & SET C
; X7757 0636YY SKPDN LINC ;BYTE READY?
; X7760 000777 JMP .-1 ;NO: WAIT
; X7761 0605YY DIAS 0,LINC ;YES: GET BYTE
; X7762 107363 ADDCS 0,1,SNC ;MERGE: ANOTHER?
; X7763 000774 JMP .-4 ;YES: GET IT
; X7764 125305 MOVS 1,1,SNR ;NO: SWAP BACK: ZERO?
; X7765 000771 JMP GET ;YES: TRY AGAIN
; X7766 045041 STA 1,41,2 ;STORE IT
; X7767 001400 JMP 0,3 ;RETURN WITH WORD
; X7770 0605YY BOOT: DIAS 0,LINC ;START LINCTAPE
; X7771 030764 LDA 2,COUNT ;SET WORD COUNTER
; X7772 004764 JSR GET ;GET A WORD
; X7773 151404 INC 2,2,SZR ;INCR & TEST
; X7774 000776 JMP .-2 ;NOT THRU
; X7775 000002 JMP MANLD ;GO TO MAN PRELOAD
; X7776 ; RESERVE FOR BINARY LOADER ADDRESS
; X7777 ; RESERVE FOR BINARY LOADER JUMP
;
; WHERE:
; X7777 = HIGHEST CORE LOCATION
;
; CORE X CORE X
; 4 K 0 20 K 4
; 8 K 1 24 K 5
; 12 K 2 28 K 6
; 16 K 3 32 K 7
;
; YY = LINCTAPE DEVICE NUMBER (USUALLY 74)

```



```

;      <<<<< PROGRAM SEQUENCE >>>>>
;
; THERE ARE FOUR SECTIONS TO THE COMPLETE BOOTSTRAP
; ROUTINE, NOT INCLUDING THE HARDWARE ROUTINES.
; THESE FOUR SECTIONS RESIDE IN THE FIRST THREE
; BLOCKS OF LINTAPE:
;   (1) PRELOADER
;   (2) UTILITY LOADER
;   (3) LINTAPE UTILITIES
;   (4) EXECUTIVE SYSTEM ROUTINE.
; REFER TO THE "HOW TO USE THE NOVA COMPUTERS"
; MANUAL, SECTIONS 2.3 AND 3.3 FOR DETAILS ON THE
; HARDWARE LOADERS.
;
; THE PRELOADER IS NEAR THE END OF BLOCK -10 OF THE
; LINTAPE IN BYTE FORM. THE BEGINNING OF BLOCK
; -10 IS ALL ZEROES. THE UTILITY LOADER, ALSO
; IN BYTE FORM, IS AT THE BEGINNING OF BLOCK -7.
; THE UTILITIES ARE IN WORD FORM AT THE END OF BLOCK
; -7, AND THE EXECUTIVE SYSTEM, IN WORD FORM, FILLS
; BLOCK -6.
;
; THE SUPERNOVA OR THE MANUAL BOOTSTRAP SKIPS
; LEADING ZEROES, AND LOADS THE PRELOADER
; PROGRAM FROM LINTAPE BLOCK -10 INTO CORE
; AT LOCATIONS 0 THRU 40. THE SUPERNOVA
; THEN JUMPS TO LOC 40, WHILE THE MANUAL
; BOOTSTRAP JUMPS TO LOC 2 OF THE PRELOADER.
;
; THE PRELOADER SETS THE DEVICE NUMBER AND IN TURN
; LOADS THE UTILITY LOADER FROM BLOCK -7 INTO CORE
; LOCATIONS 142 THRU 216, AND EXECUTES AT LOC 216.
;
; THE NOVA 800/1200 AUTOLOADER LOADS AND EXECUTES
; ITS OWN BOOTSTRAP FROM HARDWARE INTO LOCATIONS
; 0 THRU 37. IT THEN LOADS THE PRELOADER (WHICH
; IS IGNORED) AND THE UTILITY LOADER INTO CORE
; LOCATIONS 100 THRU 216, AND EXECUTES THE
; UTILITY LOADER AT LOCATION 216.
;
; THE UTILITY LOADER IS THUS LOADED AND EXECUTED
; AT 216 BY ANY OF THE BOOTSTRAP CONFIGURATIONS.
; IT SIZES CORE, AND LOADS THE UTILITIES JUST BELOW
; THE BINARY TAPE LOADER AT X7600.
;
; THE LINC UTILITIES THEN REST AT X7400 THRU X7577.
; THE PROGRAM THEN JUMPS TO "START" IN THE UTILITIES,
; READS THE EXECUTIVE SYSTEM FROM BLOCK -6 INTO CORE
; LOCATIONS X7000 THRU X7377, AND FINALLY STOPS
; THE TAPE AND JUMPS TO LOCATION X7377 WITH
; AC3 = ADDRESS OF "CLINC" (X7400) OF THE UTILITIES.
;
; SOME LOCATIONS NEAR THE BOTTOM OF CORE ARE
; WIPED OUT BY THE BOOTSTRAP PROCESS. THEY ARE:
;   SUPERNOVA      MANUAL      AUTOLOADER
;   0- 40          0- 40        0-37
;   142-216        142-216      100-216
;   377           377          377

```

; NOW THE PRELOADER PROGRAM

;

```

000010      .RDX  8
000002      .LOC  2
000002 021775  MANLD: LDA  0,-3,3 ; MANUAL ENTRY LOC: GET D.N.
000003 000005      JMP  .+2
000004 060477  PRELOD: READS 0 ; GET DEVICE NUMBER
000005 024026      LDA  1,C77
000006 123400      AND  1,0 ; MASK 6 BITS
000007 024030      LDA  1,GET+1
000010 107000      ADD  0,1
000011 044030      STA  1,GET+1 ; SET SKIP COMMAND
000012 024032      LDA  1,GET+3
000013 107000      ADD  0,1
000014 044032      STA  1,GET+3 ; SET INPUT COMMAND
000015 126440      SUBO  1,1 ; CLEAR AC1 & RESET CARRY
000016 004030      JSR  GET+1 ; GO AFTER BYTE
000017 101065      MOVC  0,0,SNR ; ZERO BYTE?
000020 000016      JMP  .-2 ; YES: IGNORE IT
000021 004027      JSR  GET ; NO: GET NEXT FULL WORD
000022 046025      STA  1,@PTR1 ; STORE THE WORD
000023 010142      ISZ  142 ; LAST WORD?
000024 000021      JMP  .-3 ; NO: GET ANOTHER WORD
000025 000141  PTR1: 141 ; POINTER TO STORE & JUMP
000026 000077  C77: 77
; GET A WORD SUBR. GET A BYTE SUBR
000027 126420  GET: SUBZ  1,1 ; CLEAR AC1 & SET CARRY
000030 060600      SKPDN 0 ; BUFFER READY?
000031 000030      JMP  .-1 ; NO: WAIT
000032 060500      DIAS  0,0 ; YES: INPUT THE BYTE
000033 107363      ADDCS 0,1,SNC ; SWAP BYTES. NEED ANOTHER?
000034 000030      JMP  .-4 ; YES: GO GET IT
000035 125300      MOVS  1,1 ; NO: SWAP BACK
000036 001400      JMP  0,3 ; RETURN WITH WORD/BYTE
000037 177777      -1
000040 000004  FORTY: JMP  PRELOD ; SUPERNOVA ENTRY LOCATION

```

^^^

```

; NOW THE UTILITY LOADER
;
000010      .RDX      8
000077      .LOC      77
000077 000377 SYNC:    377      ; SYNC BYTE
001000 177661 COUNT:   SYNC-END ; WORD COUNTER
0000142      .LOC      142
001042 177723      .-END-1
; SET DEVICE NUMBER
001043 020030 GOGO:    LDA      0,GET+1 ; GET I/O WORD
001044 024213      LDA      1,K77
001045 123400      AND      1,0      ; GET DEVICE NUMBER
001046 024206      LDA      1,GETW
001047 107000      ADD      0,1
001050 044206      STA      1,GETW ; SET SKIP COMMAND
001051 024210      LDA      1,GETW+2
001052 107000      ADD      0,1
001053 044210      STA      1,GETW+2 ; SET INPUT COMMAND
; SIZE CORE
001054 020214      LDA      0,ONEK ; MEMORY SIZE INCREMENT
001055 034215      LDA      3,HIGH ; HIGHEST OPEN MEMORY
001056 116400      SUB      0,3      ; MOVE DOWN TO NEXT CORE
001057 055777      STA      3,-1,3 ; TRIAL STORAGE
001060 031777      LDA      2,-1,3 ; GET IT AGAIN
001061 156414      SUB#     2,3, SZR ; TEST FOR MATCH
001062 000156      JMP      -4      ; NO MATCH: TRY AGAIN
; SKIP ZERO BYTES
001063 004206      JSR      GETW ; AC2 = HIGHEST OPEN CORE
001064 101025      MOVZ     0,0, SNR ; IGNORE LEADING ZEROES
001065 000163      JMP      -2
; LOAD THE UTILITIES
001066 040214      STA      0,ONEK ; SAVE COUNT "LTSIZ"
001067 113000      ADD      0,2      ; POINT TO LOAD ADDR
001070 050213      STA      2,K77 ; SAVE POINTER
001071 004206      JSR      GETW ; GET A WORD
001072 041000      STA      0,0,2 ; STORE IT
001073 151400      INC      2,2      ; INCR POINTER
001074 010214      ISZ      ONEK ; INCR COUNTER
001075 000171      JMP      -4      ; IF NOT DONE, GO BACK
; SET UP TO LOAD KEYBOARD EXEC
001076 030213      LDA      2,K77 ; IF DONE, GET 1ST UTIL LOC
001077 051170      STA      2,LLOC-CLINC,2 ; & PUT IN LLOC
002000 025163      LDA      1,SIZE-CLINC,2 ; GET WORDS/BLOCK
002001 132400      SUB      1,2      ; SET 1ST CORE LOC
002002 126520      SUBZL    1,1      ; SET NO OF BLOCKS TO 1
002003 020212      LDA      0,BLOCK ; SET NEXT BLK NO
002004 034213      LDA      3,K77
002005 001577      JMP      START-CLINC,3 ; GOTO START
; GET WORD SUBROUTINE
002006 063600 GETW:    SKPDN    0      ; BUFFER READY?
002007 000206      JMP      -1      ; NO: WAIT
002010 060500      DIAS     0,0      ; READ WORD INTO AC0
002011 001400      JMP      0,3      ; RETURN WITH FULL WORD
002012 177772 BLOCK:   -6
002013 000077 K77:     77
002014 001000 ONEK:    1000
002015 100600 HIGH:    77600+1000 ; SAVE BINARY LOADER
002016 000143 END:     JMP      GOGO ; ENTER BOOTSTRAP HERE

```

^^^

APPENDIX B. LINTAPE UTILITIES

THESE UTILITIES ARE SHOWN ASSEMBLED FOR A 4K MACHINE. HOWEVER, THEY ARE POSITION INDEPENDENT, AND THEREFORE WILL BE IDENTICAL FOR ANY SIZE MACHINE.

```

; NOW THE LINTAPE UTILITIES -----
;
; BLOCK -7 MUST CONTAIN ZEROES BETWEEN THE
; LAST WORD OF THE UTILITY LOADER ADN "LTSIZ".
000010      .RDX 8
007377      .LOC 7377
07377 177600 LTSIZ:  .-START ; LINTAPE UTILITY SIZE
;
; ENTRIES TO LINC UTILITIES
;   WLINC:  WRITE & CHECK
;   RLINC:  READ & CHECK
;   CLINC:  CHECK ONLY
;*** USER MUST SELECT DRIVE BEFORE CALL WITH "DOB -,74"
; ALL CALLS MADE BY 'JSR' TO ONE OF THE ABOVE,
;   WITH AC0= FIRST BLOCK #
;         AC1= NUMBER OF BLOCKS TO BE PROCESSED
;         AC2= FIRST CORE ADDRESS
;
;         AC1 MAY =0. THIS IS THE "FIND" FUNCTION.
;         AC2 IF NEGATIVE, REPRESENTS THE
;         ONE'S COMPL OF THE REAL ADDRESS, AND CAUSES
;         THE BLOCK SEARCH TO START IN REVERSE.
;
; NORMAL RETURNS ARE INDICATED BY AC1=0.
;         AC2= NEXT CORE ADDRESS
;         AC0= NEXT BLOCK #
;
; ABNORMAL RETURNS HAVE THE ERROR CODE IN AC1:
;         AC1=1  CHECKSUM ERROR. AC0= BAD BLOCK #
;
;         AC1=2  BLOCK SIZE ERROR. AC0= BAD BLOCK.
;         AC2= EXCESS OF MARKS IN BLOCK.
;         AC3= EXPECTED #.
;
;         AC1=4  ILLEGAL BLOCK. AC0= TARGET BLOCK.
;         AC2= NEXT CORE ADDR.
;         AC3= HIGHEST LEGAL BLOCK.
;
;         AC1=8  DRIVE STATUS ERROR. AC3= DRIVE STATUS,
;         BIT 1= PROTECTED, BIT 0= NOT READY.
;
07400 054431 CLINC:  STA 3,SAC3
07401 152400      SUB 2,2 ;ADDRESS DOESN'T MATTER
07402 000417      JMP CHKZ
07403 054426 RLINC:  STA 3,SAC3
07404 034430      LDA 3,D2R ; SET READ RTNE. TO STORE DATA
07405 000415      JMP READZ
07406 054423 WLINC:  STA 3,SAC3
07407 034423      LDA 3,D1W
07410 054510      STA 3,D1XX ; SET UP FOR WRITE
07411 044501      STA 1,D2XX ;SAVE PARAMS
07412 050416      STA 2,SAC2
07413 004423      JSR DO ; FIND & WRITE BLOCKS

```

^^^

```

07414 024476 RAW: LDA 1,D2XX ;RESTORE PARAMS
07415 122400 SUB 1,0
07416 030412 LDA 2,SAC2
07417 151113 MOVL# 2,2,SNC ;MAKE ADDR. NEG FOR REVERSE
07420 150000 COM 2,2
07421 034473 CHKZ: LDA 3,D2C ; NO STORE ON CHECK
;
07422 054470 READZ: STA 3,D2XX
07423 034410 LDA 3,D1RC
07424 054474 STA 3,D1XX ; SET UP FOR READ OR CHECK
07425 004411 JSR D0 ; FIND & READ BLOCKS
07426 060274 EXIT: NIOC LINC ; STOP DRIVE
07427 002402 JMP @SAC3 ; RETURN TO CALLER
07430 000000 SAC2: 0
07431 000000 SAC3: 0
;
07432 021000 D1W: LDA 0,0,2 ; DATA FOR WRITE SWITCH
07433 000750 D1RC: JMP READ-D1XX,1 ; FOR READ SWITCH
07434 132512 D2R: SUBL# 1,2,SZC ;DO THIS FOR READ, NOT CHECK
07435 000000 RETU: 0
;
07436 054777 D0: STA 3,RETU
07437 075474 DIB 3,LINC ; CHECK DRIVE READY
07440 175112 MOVL# 3,3,SZC
07441 000446 JMP E4
07442 151113 MOVL# 2,2,SNC ; LOOK AT ADDR.
07443 000410 JMP FINDF ; IF POS, START FORWARD
07444 150000 COM 2,2 ; IF NEG, START REVERSE
;
07445 176400 FINDR: SUB 3,3 ; ENTER HERE FOR REV.
07446 162000 ADC 3,0 ;POINT TO TARGET-1
07447 060374 NIOP LINC ;START REV
07450 004467 JSR GETBLOCK
07451 101401 FINDN: INC 0,0,SKP
07452 000776 JMP .-2 ; KEEP GOING IF ABOVE OR ON
07453 060174 FINDF: NIOS LINC ; ENTER HERE FOR FWD.
07454 004463 JSR GETBLOCK
07455 000777 JMP .-1 ; KEEP GOING IF BELOW
07456 175224 MOVZR 3,3,SZR ; FOUND TARGET IF =0
07457 000766 JMP FINDR
07460 125005 FOUND: MOV 1,1,SNR ;LAST BLOCK?
07461 002754 JMP @RETU ; YES, EXIT FROM "D0"
07462 166000 ADC 3,1 ;AC3=0. DECR BLOCK COUNTER
07463 040474 STA 0,TEMP1
07464 044474 STA 1,TEMP2
07465 024476 LDA 1,SIZE
07466 147000 ADD 2,1 ;POINT TO END OF BLOCK.
07467 000431 JMP D1XX

```

^^^

```

07470 063674 READ: SKPDN LINC ; WAIT FOR DATA
07471 000777 JMP .-1
07472 063474 SKPBN LINC
07473 000416 JMP RDAT
07474 060474 RCHK: DIA 0,LINC ; INPUT CHECKSUM
07475 116405 SUB 0,3,SNR
07476 000434 JMP SCHK ; SHOULD = ACCUM. CHKSM
07477 024465 E1: LDA 1,C1 ; CHECKSUM ERROR
07500 000403 JMP .+3
07501 034462 E2: LDA 3,SIZE
07502 024463 LDA 1,C2
07503 020454 LDA 0,TEMP1
07504 000722 JMP EXIT
07505 024461 E3: LDA 1,C4 ; ILLEGAL BLOCK NUMBER
07506 000720 JMP EXIT
07507 024460 E4: LDA 1,C8 ; DRIVE STATUS ERROR
07510 000716 JMP EXIT
07511 060474 RDAT: DIA 0,LINC ; INPUT DATA WORD
07512 132512 D2XX: SUBL# 1,2,SZC ; "JMP .+2" FOR CHECK
07513 041000 STA 0,0,2
07514 000402 D2C: JMP .+2
07515 061074 WDAT: DOA 0,LINC ; WRITE DATA
07516 117000 BLOOP: ADD 0,3 ; UPDATE CHKSM ACCUM.
07517 151400 INC 2,2 ; UPDATE POINTER
07520 021000 D1XX: LDA 0,0,2 ; FOR READ & CHECK, "JMP READ"
07521 063074 DOC 0,LINC ; WRITERS ON
07522 063674 SKPDN LINC
07523 000777 JMP .-1 ; WAIT FOR DATA, CHECK MARK
07524 063474 SKPBN LINC
07525 000770 JMP WDAT ; DATA MARK
07526 075074 WCHK: DOA 3,LINC ; WRITE CHECKSUM
07527 075474 DIB 3,LINC ; INPUT DRIVE STATUS
07530 175004 MOV 3,3,SZR
07531 000756 JMP E4 ; MUST BE READY & UNPROTECTED
07532 132414 SCHK: SUB# 1,2,SZR ; WAS BLOCK RIGHT SIZE?
07533 000746 JMP E2
07534 020423 NEXT: LDA 0,TEMP1 ; BLOCK FINISHED
07535 024423 LDA 1,TEMP2 ; RESTORE BLOCK COUNTER
07536 000713 JMP FINDN ; NEXT BLOCK
;
;

```

^^^

```
07537 054420 GETBLOCK: STA 3,TEMP1
07540 034421 LDA 3,MLIM ;CHECK TARGET LIMITS
07541 162432 SUBZ# 3,0,SZC ; OK IF BETWEEN MLIM & PLIM
07542 000405 JMP WAIT
07543 034417 LDA 3,PLIM
07544 162032 ADCZ# 3,0,SZC
07545 000740 JMP E3 ; NO SUCH BLOCK
07546 074474 DIA 3,LINC ;CLEAR SYNC FLOP
07547 063474 WAIT: SKPBN LINC ;GET BLOCK #
07550 000777 JMP WAIT
07551 063774 SKPDZ LINC
07552 000774 JMP WAIT-1 ;WAS A CHECK MARK
07553 074474 DIA 3,LINC ;INPUT IT
07554 116543 SUBOL 0,3,SNC ;SKIP IF BELOW BLOCK WANTED
07555 010402 ISZ TEMP1
07556 002401 JMP @TEMP1
07557 000000 TEMP1: 0
07560 000000 TEMP2: 0
07561 177770 MLIM: 177770 ;LOWEST BLOCK
07562 000620 PLIM: 620 ;HIGHEST BLOCK
07563 000400 SIZE: 400 ;BLOCK LENGTH
07564 000001 C1: 1
07565 000002 C2: 2
07566 000004 C4: 4
07567 000010 C8: 10
;
```

^^^

```
;
; WHAT FOLLOWS IS A BOOT , WHICH CAN BE
; USED TO LOAD ALL BUT ONE BLOCK OF MEMORY,
; FROM DRIVE 0. THIS PROCEDURE IS USED BY
; THE BOOT PROG.
; JUMP TO "START" WITH:
;     AC0=FIRST BLOCK TO BE READ,
;     AC1=# BLOCKS TO READ,
;     AC2= LOAD ADDR.
; A HALT @ "PAUSE" INDICATES ERROR.
; IF NO ERROR, CONTROL IS PASSED TO THE
; LAST WORD LOADED, WITH :
;     AC2= ADDR OF LAST WORD LOADED +1,
;     AC3= ADDR OF "CLINC" IN UTILITIES.
;
07570 000000 LLOC:      0
07571 004612      JSR    RLINC
07572 034776      LDA    3,LLOC
07573 125005      MOV    1,1,SNR
07574 001377      JMP    -1,2
07575 062677 PAUSE:    IORST      ;STOP & SELECT DRIVE 0
07576 063077      HALT        ;IF ERROR, SET AC'S & CONTINUE
07577 000772 START:    JMP    .-6    ;  SYSTEM START BLOCK
                        .END
```


APPENDIX C. KEYBOARD EXECUTIVE

LINCTAPE KEYBOARD EXECUTIVE ROUTINE 5/71

THE LINC EXECUTIVE INTERPRETS TYPED COMMANDS, AND PERFORMS LINCTAPE OPERATIONS ACCORDINGLY. THE PROGRAM MANIPULATES INTEGRAL NUMBERS OF LINC BLOCKS (256 WORDS EACH) BETWEEN TAPE AND ANY CONTIGUOUS CORE LOCATIONS.

COMMAND STRUCTURE

COMMANDS ARE OF TWO MODES:

A,B,C,DX GENERAL MODE
AND Y AUTOMATIC MODE.

SYMBOL DEFINITIONS:

- A =ADDRESS, AN OCTAL DIGIT STRING, FOLLOWED BY A COMMA. THE LAST 5 DIGITS TYPED REPRESENT THE FIRST CORE ADDRESS. IF ONLY A COMMA IS TYPED, THE VALUE WILL BE INTERPRETED AS 0.
- B =BLOCK, THE FIRST BLOCK NUMBER; SAME GENERAL DEFINITION AS 'A', EXCEPT THE STRING IS INTERPRETED AS A 16-BIT SIGNED NUMBER. (2'S COMPLEMENT CONVENTION)
- C =COUNT, THE COUNT OF BLOCKS TO BE PROCESSED; SAME DEFINITION, BUT A 16-BIT UNSIGNED NUMBER.
- D =DRIVE, THE DRIVE NUMBER; AN OCTAL DIGIT STRING NOT FOLLOWED BY A COMMA. ONLY THE LEAST SIGNIFICANT (LAST TYPED) 4 BITS ARE USED.
- X =ONE OF THE FOLLOWING SINGLE CHARACTERS:
 - C CHECK - FIND AND VERIFY BLOCK NUMBERS AND CHECKSUMS.
 - R READ - FIND, CHECK AND TRANSFER INTO CORE.
 - W WRITE - FIND, WRITE FROM CORE, AND CHECK (TWO PASSES).

THE INTERPRETER CATCHES INVALID CHARACTERS TYPED, AND CHECKS COMMAND FORMAT, BUT IT IS POSSIBLE TO "BOMB" THE SYSTEM BY LOADING OVER THE EXECUTIVE PROGRAM, FOR EXAMPLE. THE EXECUTIVE RESIDES AT X7000-X7377 OCTAL (WHERE X7777 IS THE HIGHEST CORE LOCATION), AND IT CALLS ON THE LINC UTILITIES AT X7400-X7577 OCTAL. IN OTHER WORDS, THE MAXIMUM NUMBER OF BLOCKS YOU CAN READ IS 16 BLOCKS IN A 4K MACHINE, OR ALL BUT THE HIGHEST 1000 LOCATIONS OF CORE. THERE IS NO RESTRICTION ON CHECKING.

THE DRIVE MUST BE IN TENSION MODE AND, IF WRITING, THE DRIVE PROTECT LIGHT MUST BE OFF. IF ON, THE TAPE WILL NOT BE WRITTEN, AND AN ERROR WILL BE INDICATED.

THE EXECUTIVE MAY BE RESTARTED AS FOLLOWS:

PRESS 'RESET'

SET DATA SWITCHES TO X7000 OCTAL

PRESS 'START'

AUTOMATIC MODE

IN THE AUTOMATIC MODE, TYPING A SINGLE CHARACTER WILL READ IN THE DESIRED PROGRAM. THIS MODE WILL ONLY READ FROM DRIVE 0. IT WILL NOT WRITE, NOR WILL IT ACCESS ANY OTHER DRIVE.

FOR INSTANCE, TYPING "A" CAN READ THE ASSEMBLER FROM THE TAPE ON DRIVE 0 INTO CORE. AS WITH THE GENERAL MODE, THE SYSTEMS RETURNS TO THE KEYBOARD EXEC AFTER READING, AND THE NORMAL START PROCEDURE FOR THAT PROGRAM MUST BE FOLLOWED TO EXECUTE IT.

THE NECESSARY INFORMATION FOR READING IS STORED IN A TABLE IN THE KEYBOARD EXEC. IT IS ASSUMED THAT THE PROPER PROGRAM WILL BE FOUND ON THE TAPE. IN GENERAL, IT IS ADVISABLE TO MAINTAIN THE TABLE IN THE KEYBOARD EXEC TO MATCH THE PROGRAMS ON THAT PARTICULAR TAPE. IN THIS WAY, THE SYSTEM, AFTER BOOTSTRAPPING, WILL FUNCTION PROPERLY.

WHEN PROGRAMS ARE ADDED TO OR DELETED FROM THE TAPE, THE KEYBOARD EXEC MUST BE UPDATED IF THE AUTOMATIC MODE IS TO HANDLE IT PROPERLY. THIS TABLE STARTS AT LOCATION YY212 (WHERE YY000 IS THE FIRST LOCATION IN THE EXEC). THE TABLE REQUIRES A GROUP OF FOUR PARAMETERS FOR EACH PROGRAM:

- (1) KEYBOARD LETTER
- (2) FIRST CORE LOCATION
- (3) FIRST BLOCK NUMBER
- (4) NUMBER OF BLOCKS

THE SEQUENCE OF THE GROUPS DOES NOT MATTER, BUT THE SEQUENCE OF THE PARAMETERS WITHIN THE GROUP DOES. THERE IS ROOM IN THE TABLE FOR 23 LETTERS.

THE PROCEDURE FOR CHANGING THE TABLE IS:

- (1) ENTER THE EXECUTIVE ROUTINE
- (2) LOAD THE DEBUG III ROUTINE
- (3) PUT THE TAPE WITH THE EXECUTIVE ROUTINE THAT IS TO BE UPDATED ON DRIVE 0
- (4) READ A FRESH COPY OF THE EXEC INTO WORKING CORE (THE EXEC IS ON BLOCK -6, OR 177772):
1000,177772,1,0R
NEVER TRY TO UPDATE THE EXEC "IN PLACE".
- (5) ENTER THE DEBUG ROUTINE
- (6) LIST THE TABLE, FROM LOCATION 1212 UNTIL THE FIRST (ASCII LETTER) WORD IN A GROUP IS ZERO, INDICATING THE END OF THE TABLE (A LOCATION ENDING IN -2 OR -6.)

- (7) ADD, CHANGE, OR DELETE GROUPS IN THE TABLE AS REQUIRED. BE SURE TO PUT THE NUMBERS IN THE CORRECT SEQUENCE, AND TO PUT THE "END OF TABLE" ZERO AFTER THE LAST SET. NOTE ALSO THAT THE ASCII IS 7, NOT 8 BIT CODE. A TYPICAL SEQUENCE IS:

001242	000113	ASCII LETTER K
001243	001000	1ST CORE LOCATION
001244	000030	1ST BLOCK NUMBER
001245	000014	NUMBER OF BLOCKS
001246	000000	END OF TABLE

THE TABLE CAN, OF COURSE, BE UPDATED BY OTHER MEANS, SUCH AS THE FRONT PANEL SWITCHES.

- (8) WRITE THE UPDATED VERSION BACK ONTO LINCTAPE:

1000,177772,1,0W

- (9) REBOOT, AND TEST THE NEW ROUTINE.

TO EXECUTE ANY LOADED PROGRAM, YOU MUST FOLLOW NORMAL INSTRUCTIONS FOR THAT PROGRAM. THE LINC EXEC DOES NOT START PROGRAMS.

ERRORS ARE INDICATED BY A RETURN TO THE EXECUTIVE WITH ? TYPED, THEN * ERRORS CAN BE :

- 1.TAPE NOT IN TENSION.
 - 2.TAPE PROTECTED AGAINST WRITE.
 - 3.CHECKSUM ERROR; YOU HAVE A BAD BLOCK ON TAPE, OR YOU PRESSED PROTECT SWITCH WHILE WRITING. RETRY.
 - 4.BAD TAPE, NEEDS REMARKING.
 - 5.YOU TRIED TO FIND A BLOCK NOT ON THE TAPE.
- LIMITS ARE 177772 (-6) THROUGH 0, TO 617, OCTAL.
- 6.INVALID COMMAND.

SUCCESSFUL COMPLETION OF A COMMAND IS INDICATED BY A RETURN TO THE EXECUTIVE WITH * TYPED.

EXAMPLES

*100,2,1,0R

*

READ, STARTING AT CORE ADDRESS 100,
ONE BLOCK, STARTING AT BLOCK 2, DRIVE 0.

*0,7777777777,1,1W

*

WRITE BLOCK -1 FROM CORE ADDR 0,DRIVE 1

*0,177777,1,1W

?

*

ERROR. SAME COMMAND AS ABOVE.

*0,0,620,0C

*,,620,0C

CHECK TAPE BLOCKS 0 THROUGH 617.
SAME THING.

*A

*

LOAD EXTENDED ASSEMBLER.

THIS ROUTINE IS LISTED AS ASSEMBLED AT LOCATION 7000.
EXCEPT FOR THE POINTERS, WHICH ARE PRESET AT BOOT TIME, IT IS
POSITION INDEPENDENT, AND WILL BE THE SAME FOR ANY SIZE CORE.

; KEYBOARD EXEC 5/71/JJM

; THESE ROUTINES ALLOW THE USER TO USE THE LINC
; TAPE UTILITIES FROM THE KEYBOARD.
; THIS PROGRAM ACCEPTS TWO TYPES OF COMANDS
; TYPE 1 IS THE SINGLE LETTER TYPE WHICH IS USED
; PRIMARILY TO READ IN SYSTEM PROGRAMS FROM
; DRIVE 0 ONLY. THE PROGRAM CONTAINS A LOOKUP
; TABLE FOR THESE COMMANDS WHICH CAN BE EASILY
; UPDATED WITH DEBUGER.
; THE TYPE TWO COMANDS ARE READ, WRITE AND
; CHECK. THESE COMMANDS REQUIRE 4 PARAMETERS
; AS EXPLAINED IN THE INSTRUCTION BOOK

007000		.LOC	7000	
07000	000504	EXEC:	JMP	ELIN ; OUTPUT CR "**
07001	102400		SUB	0,0 ; CLEAR AC0
07002	040571		STA	0,TEM1 ; CLEAR INPUT ARRAY
07003	040571		STA	0,TEM2
07004	040571		STA	0,TEM3
07005	040571		STA	0,TEM4
07006	020552		LDA	0,C4 ; SET RE-TRY COUNT
07007	040571		STA	0,ERCO
07010	004503		JSR	INOC ; INPUT OCTAL NUMBER
07011	044562		STA	1,TEM1
07012	030552		LDA	2,C54 ; COMA??
07013	142415		SUB#	2,0,SNR
07014	000422		JMP	COMA
07015	024543		LDA	1,C4 ; LOOK UP INPUT CHARACTER
07016	034573		LDA	3,TABL
07017	031400	EAGN:	LDA	2,0,3
07020	151005		MOV	2,2,SNR ; IF END OF TABLE GRIPE
07021	000457		JMP	NOGO
07022	142415		SUB#	2,0,SNR ; IF MATCH GO TO IT
07023	000403		JMP	FNDI
07024	137000		ADD	1,3 ; UPDATE POINTER
07025	000772		JMP	EAGN ; AND TRY AGAIN
07026	021401	FNDI:	LDA	0,1,3 ; GET PARAMETERS AND SAVE THEM
07027	040544		STA	0,TEM1
07030	021402		LDA	0,2,3
07031	040543		STA	0,TEM2
07032	021403		LDA	0,3,3
07033	040542		STA	0,TEM3
07034	020536		LDA	0,CR
07035	000414		JMP	COM1-1 ; GO TO IT

^^^

```

07036 004455 COMA: JSR INOC ; GET NEXT NUMBER
07037 044535 STA 1,TEM2 ; SAVE IT
07040 030524 LDA 2,C54 ; CHECK FOR COMA
07041 142414 SUB# 2,0,SZR
07042 000436 JMP NOGO
07043 004450 JSR INOC ; GET NEXT NUMBER
07044 044531 STA 1,TEM3
07045 142404 SUB 2,0,SZR
07046 000432 JMP NOGO
07047 004444 JSR INOC
07050 044526 STA 1,TEM4
07051 034530 COM1: LDA 3,TABL1 ; LOOK UP CHARACTER
07052 031400 LDA 2,0,3
07053 175400 INC 3,3
07054 175400 INC 3,3
07055 151015 MOV# 2,2,SNR
07056 000422 JMP NOGO ; IF END OF TABLE GRIPE
07057 142414 SUB# 2,0,SZR
07060 000772 JMP COM1 ; IF NOT MATCH TRY AGAIN
07061 035777 LDA 3,-1,3 ; GET EXECUTION ADDRESS
07062 054515 STA 3,FDDR ; SAVE EXEC ADDRESS

```

```

07063 020511 TRYAGN: LDA 0,TEM2 ; STARTING BLOCK #
07064 024511 LDA 1,TEM3 ; NUMBER OF BLOCKS
07065 030511 LDA 2,TEM4 ; DRIVE #
07066 072074 DOB 2,74 ; SELECT DRIVE
07067 030504 LDA 2,TEM1 ; STARTING CORE LOCATION
07070 034507 LDA 3,FDDR ; GET EXECUTION ADDRESS
07071 005400 JSR 0,3 ; GO TO IT
07072 125015 MOV# 1,1,SNR ; IF NO ERROR RETURN TO START
07073 000705 JMP EXEC
07074 125223 MOVZR 1,1,SNC ; IF CHECKSUM TRY AGAIN
07075 000403 JMP NOGO ; ELSE GIVE UP
07076 014502 DSZ ERCO
07077 000764 JMP TRYAGN ; TRY THREE TIMES

```

```

07100 020462 NOGO: LDA 0,C15
07101 004447 JSR 0A0
07102 020466 LDA 0,CQUES
07103 004445 JSR 0A0
07104 020456 ELIN: LDA 0,C15
07105 004443 JSR 0A0
07106 020463 LDA 0,CSTAR
07107 004441 JSR 0A0
07110 020453 LDA 0,C40
07111 004437 JSR 0A0
07112 000667 JMP EXEC+1

```

^^^

```

;          CONVERT AN ASCII OCTAL CHARACTER STRING TO A BINARY
;          NUMBER IN AC1, AND A BREAK CHARACTER IN AC0

07113 054425 INOC:  STA      3,RTRN  ; SAVE RETURN ADDRESS
07114 050425      STA      2,TEM0   ; SAVE AC2
07115 102400      SUB      0,0
07116 040424      STA      0,OCTL   ; CLEAR RESULT WORD
07117 004424 INOC1: JSR      1A0     ; GET A CHARACTER
07120 030445      LDA      2,C60
07121 034445      LDA      3,C67
07122 162033      ADCZ#    3,0,SNC  ; TEST FOR 60<=N<=67
07123 112032      ADCZ#    0,2,SZC
07124 000411      JMP      EINOC    ; NO MUST BE BREAK CHARACTER
07125 142400      SUB      2,0      ; MAKE IT OCTAL
07126 024414      LDA      1,OCTL
07127 125120      MOVZL    1,1      ; OLD TIMES 8
07130 125120      MOVZL    1,1
07131 125120      MOVZL    1,1
07132 107000      ADD      0,1      ; NEW PLUS OLD
07133 044407      STA      1,OCTL
07134 000763      JMP      INOC1    ; LOOP UNTIL BREAK CHARACTER

07135 030404 EINOC: LDA      2,TEM0   ; RESTORE AC2
07136 024404      LDA      1,OCTL   ; RESULT TO AC1
07137 002401      JMP      @RTRN

07140 000000 RTRN:  0              ; SAVE RETURN LOCATION
07141 000000 TEM0:  0              ; STORAGE FOR AC2
07142 000000 OCTL:  0              ; RESULT

```

```

;          INPUT AND ECHO TELETYPE CHARACTER AND MASK PARITY

07143 063610 IA0:   SKPDN    TTI      ; WAIT FOR INPUT CHARACTER
07144 000777      JMP      .-1
07145 060610      DIAC      0,TTI    ; INPUT CHARACTER TO AC0
07146 030421      LDA      2,C177    ; MASK OFF PARITY BIT
07147 143400      AND      2,0

07150 063511 OA0:   SKPBZ    TTO      ; WAIT FOR OUTPUT          READY
07151 000777      JMP      .-1
07152 061111      DOAS      0,TT0    ; OUTPUT AC0 AND START
07153 030407      LDA      2,C15
07154 142434      SUBZ#    2,0,SZR   ; IF CR OUTPUT LF
07155 001400      JMP      0,3
07156 020403      LDA      0,C12
07157 000771      JMP      OA0

```

^^^

		;	CONSTANTS
07160	000004	C4:	4
07161	000012	C12:	12
07162	000015	C15:	15
07163	000040	C40:	40
07164	000054	C54:	54
07165	000060	C60:	60
07166	000067	C67:	67
07167	000177	C177:	177
07170	000077	CQUES:	"?
07171	000052	CSTAR:	"*
07172	000122	CR:	"R
07173	000000	TEM1:	0
07174	000000	TEM2:	0
07175	000000	TEM3:	0
07176	000000	TEM4:	0
07177	000000	FDDR:	0
07200	000000	ERCO:	0


```

;          VALUES IN THIS TABLE WILL BE FILLED IN BY THE
;          SIZE ROUTINE AT LOAD TIME
07201 000000 TABL1: 0          ; ADDRESS OF TABLE
07202 000122          ; READ LINC TAPE
07203 000000 LR:      0
07204 000103          "C
07205 000000 LC:      0
07206 000127          "W
07207 000000 LW:      0
07210 000000          ; END OF TABLE

```

```

;          AUTOMATIC MODE TABLE
;          THIS TABLE IS USED TO LOOK UP THE
;          STARTING CORE LOCATION, STARTING BLOCK #
;          AND THE NUMBER OF BLOCKS FOR THE SINGLE
;          LETTER COMMANDS.

```

```

;          THE FORM IS:
;          COMMAND LETTER
;          STARTING CORE LOCATION
;          STARTING BLOCK NUMBER
;          NUMBER OF BLOCKS
;

```

```

;          THUS:
;          07212 000104 "D
;          07213 001000 1000
;          07214 000000 0
;          07215 00014 14
;          07216 000000 0
;          WOULD LOAD LOCATIONS 1000 THRU 6777 INTO CORE
;          FROM BLOCKS 0 THRU 13 ON THE TAPE ON DRIVE 0,
;          WHEN THE LETTER "D" WAS TYPED.
;

```

```

;          THERE IS ROOM IN THE TABLE FOR 25 (DECIMAL)
;          COMMAND LETTERS.
;

```

```

07211 000000 TABL: 0          ; ADDRESS OF TABLE
07212 000000          ; END OF TABLE

```

^^^

; THIS ROUTINE DETERMINES THE SIZE OF CORE AND
;
SETS ALL OF THE POINTERS.

007352	024421	SIZE:	.LOC	EXEC+352
07352	024421		LDA	1,C400
07353	132400		SUB	1,2
07354	141000		MOV	2,0
07355	024421		LDA	1,TABP
07356	133000		ADD	1,2
07357	051377		STA	2,-1,2
07360	024415		LDA	1,TAB2P
07361	133000		ADD	1,2
07362	051377		STA	2,-1,2
07363	054622		STA	3,LC
07364	024410		LDA	1,C3
07365	137000		ADD	1,3
07366	054615		STA	3,LR
07367	137000		ADD	1,3
07370	054617		STA	3,LW
07371	111000		MOV	0,2
07372	001000		JMP	0,2
07373	000400	C400:	400	
07374	000003	C3:	3	
07375	000010	TAB2P:	TABL-TABL1	
07376	000202	TABP:	TABL1-EXEC+1	
07377	000753		JMP	SIZE
			.END	

APPENDIX D. LINCTAPE MAP

STANDARD LINCTAPES FOR USE WITH THE NOVA COMPUTERS CONTAIN THE FOLLOWING PROGRAMS:

BLOCK NUMBER	PROGRAM
-10	PRELOADER (BYTE FORM)
-7	UTILITY LOADER (BYTE FORM)
	LINCTAPE UTILITIES
-6	KEYBOARD EXECUTIVE
-5 THRU -1	ZEROES